


INSTRUCTION

Handbook
ENG



use
installation
adjustment
maintenance

CITY CLASS

25 KR

35 KR



Caldaie • Scaldabagni • Sistemi Solari • Climatizzatori

Table of Content

Safety warnings	3
Safety warnings symbols legend	4
References to Laws and Norms	4
Personnel in charge of installation	4
Installation, use and maintenance	4
User warnings	5
Important	5
First starting up and Use	5
Installation, first starting up, maintenance and servicing	6
Appliance booklet or central plant booklet	6
Combustion checking	6
Boiler operation and servicing	6

User guide	7
The front control panel	7
Commands on the lower side	8
Commands outside the boiler	8
Commands related to Domestic Hot Water	9
Typical use	9
Preliminary operations	9
Boiler activation	10
Temperature adjustment	10
Anti-Legionella function	10
Incidental malfunctioning	11
The burner doesn't turn on	11
Shortage of domestic hot water production	11
Boiler inactivity	11
Safety shut off	11
Stand-by mode with anti-frost & anti-locking function	12
"Ambient Anti-Frost" Function	13

Installation	13
Law and regulation prescriptions for the installer	13
Dimensions and connections	14
Pump capacity diagram	14
Warnings for the installation of optional kits or special systems	15
Floor heating system	15
Specifications for intake air	15
Domestic water supply characteristics	15
Protection against freezing	16
Outdoor installation in a partially protected place	16
Positioning and fastening	16
Hydraulic system (DHW and heating)	17
Advices and suggestions to avoid vibrations and noises in the system	18
Cleaning and preservation of the systems	18
Heating system	18
Piping between the boiler and the storage unit	18

Condense drain	18
Heating system filling and pressuring	19
DHW storage tank filling	19
Gas connection	20
Electrical connections of the boiler	20
Electrical connection between the boiler and the storage unit	21
Flue systems	22
Intake/outlet flange	22
General indications	22
Examples of installation of intake and outlet ducts	24
Dimensioning the intake and outlet ducts	25
Flue system types	26
Allowed flue types	27

Adjustment and Maintenance	28
First starting up	28
Maintenance operations	29
Access to the inside of the boiler	30
Venting the primary exchanger	31
Combustion group cleaning and check	31
PCB parameters settings (technician menu)	32
Main boiler parameters (PC)	33
Combustion test	36
Power adjustment tables	38
Max heating power adjustment	38
Combustion calibration	38
Accessing the main board	39
Main board replacement	40
Board configuration codes	40
Gas conversion	40
Draining the heating system	41
Pump settings	41
Alarms - boiler block	41
Warnings for servicing	47
Technical data	48
Boiler internal components	50
Electrical diagram	51
Hydraulic diagram	52

Addendum	53
Outdoor Sensor Kit	53
Installation and setting	53
Outdoor Sensor kit and Remote Control	53
Remote Control Kit	54








This instructions manual is an essential and complementary part of the product and it is supplied together with the boiler.



Carefully read the manual, achieving all important information for a safe installation, use and servicing.

- ▶ **Carefully keep the manual**, together with the documentation of all the accessories of the boiler and of the system, for any further consultation you may need.
- ▶ **The installation** must be carried out by a qualified technician, in accordance with manufacturer instructions and with the relevant requirements of the current issue.
- ▶ **Carbon monoxide (CO) danger:** the CO is a no-smelling and no-colour gas. When a forced draught boiler with air intake from the room (appliance type B₂) is installed, permanent ventilation of the installation room is mandatory and extremely important. Ventilation must be made and sized in compliance with Laws and Rules in force. Whatever manumission, closing or neutralization of the permanent ventilation could lead to very serious consequences to people in the rooms, as intoxication by CO, permanent damage and death. Besides, the CO and O₂ mix can be explosive.
- ▶ A **qualified technician** is a person with a specific technical competence in the field of the heating appliances for domestic use and domestic hot water production, in compliance with Laws and Rules in force.
- ▶ The **operations that the user can do** are only and exclusively the ones contained in the "USER GUIDE" section.
- ▶ The manufacturer has no contractual and extra-contractual responsibility for any damage arising from wrong installation, wrong use and non-observance of current laws and instructions given by the manufacturer himself.
- ▶ **Important:** this gas boiler is used to heat the water at a temperature lower than the boiling one, at atmospheric pressure; it must be connected to an heating system and/or to a domestic hot water system, in accordance with its features and power.
- ▶ Packing items (cartons, nails, plastic bags and so on) **must not be left within children easy reach**, as they are potentially dangerous.
- ▶ **Before any cleaning or servicing operation**, disconnect the boiler from the mains electrical supply by means of the main electrical switch and stop the gas supply by means of the suitable cock.
- ▶ **In case of fault** and/or bad operation of the appliance, disconnect it immediately and do not try to repair it by yourselves.
- ▶ **Boiler servicing and repair** must be carried out exclusively by qualified technicians, which will use original spare parts. Strictly observe the above requirement, avoiding any risk of compromising the appliance safety.
- ▶ **If the appliance should be definitively dismissed**, remove or cut off any potential dangerous item.
- ▶ **When transferring the appliance** (e.g. leaving it installed after a removal or a sale of the building), make always sure that the instructions manual is close to the boiler for the future use of new owners and/or installers.
- ▶ This appliance **must be used for its clearly recommended utilization only**. Any other utilization must be considered dangerous and incorrect.
- ▶ It is strictly forbidden to use the appliance **for different purposes** than the specified ones.
- ▶ This appliance must be **installed exclusively to wall**.


Safety warnings symbols legend

 Generic safety warning	 Electrical danger (fulguration)	 Physical danger (personal damage)
 Thermal danger (burns)	 General warning or advice to avoid material damage or to achieve improvements	


References to Laws and Norms


All references to laws and laws contained in this handbook, as well as all installation, maintenance and use prescriptions and the relevant pictures, are relevant to European and/or Italian regulation.

All laws and norms in force in the territory where the installation takes place prevail on the indications contained in this handbook, that are inconsistent with them.

 All the **references to norms and national laws** mentioned in this handbook are indicative as laws and norms are subject to issues and integrations by the authorities in charge. **Also comply to eventual local norms and laws** (not mentioned in this handbook) in force in the territory where the installation takes place.

Personnel in charge of installation

 **Always comply with national and/or local regulation about WORK SAFETY of Personnel in charge of installation.**

 Always proceed with caution when handling the boiler and carrying out installation/maintenance work as metal parts may cause injuries such as cuts and abrasions. **Wear personal protection devices** (especially gloves) while doing the above mentioned operations

Installation, use and maintenance

 **Always comply with national and/or local regulation about BOILER INSTALLATION.**

User warnings

Important



In case of gas smell:

- 1 - **do not press electrical switches, use the telephone or other objects that can provoke sparks;**
- 2 - **open immediately the windows and the doors in order to cleanse the room air;**
- 3 - **close the gas supply taps;**
- 4 - **call a qualified technician.**



Do not obstruct the ventilation openings of the gas boiler room, in order to avoid possible dangerous situations as the creation of poisonous or explosive mixtures.

First starting up and Use



The first starting up and the maintenance of the boiler must be performed by a professionally qualified staff (for example the installer or the Service Centres authorized by ITALTHERM)

The latter will check that:

- ▶ the label technical data of the gas boiler correspond to those of the gas available;
- ▶ the main burner regulation is compatible with the gas boiler output;
- ▶ the chimney works correctly, expelling the combustion products;
- ▶ the air supply and the combustion products evacuation work correctly, in accordance with the requirements in force;
- ▶ the conditions for a correct ventilation are guaranteed, also when the gas boiler is located inside a closed space (with suitable characteristics).



This boiler is designed and prepared to be supplied with Natural Gas G20 (Methane). It can be set, just by means of electronic settings, but always by a qualified technician, to operate with Commercial Propane G31. It must never be used with **butane gas G30** (that can be present, pure or mixed with Propane G31, in the portable gas bottles for cookers).



The User must not touch sealed items nor break the seals. Only specialized technicians and the official technical service can break the seals of sealed items.



The boiler is fitted with safety devices that block operation the case of problems with the boiler or related systems. These devices must never be disabled: if a device intervenes frequently, have a qualified technician located the cause, even in systems to which the boiler is connected, and in the flue intake/outlet system that must be efficient and made according to the laws in force (see examples in paragraph "Flue systems" on page 22). If a boiler component has failed, you must only use original replacement parts



When the boiler is off for a long period see the Paragraph "Boiler inactivity" on page 11 for the necessary precautions about the electrical supply, the gas supply and the protection against freezing.



Do not touch the heated surfaces of the boiler, as the doors, the flue, the chimney pipe, etc., also after the boiler operation because, for a certain time, these surfaces are overheated. **Any contact with them can cause dangerous scalds.** It is then forbidden to let children or inexperienced people be close to the boiler, during its operation.

- ▶ Do not expose the wall hung gas boiler to water or other liquids sprinklings, or to vapours directly coming from gas cookers/hobs.
- ▶ Do not obstruct the air intake or flue outlet terminals, even momentarily or partially.
- ▶ Do not put any object on the gas boiler and don't leave any flammable liquid or solid materials, (e.g. paper, clothes, plastic, polystyrene) in its proximity.
- ▶ This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- ▶ If the gas boiler is going to be definitively unused, call a qualified technician to carry out all required operations, checking in particular disconnection of gas, water and electrical supplies.
- ▶ **Only for those models that draw directly from the installation room** (type B appliances installed in-door): the installation of aspirators, fireplaces or similar appliances in the room where the type B appliance is installed (and in adjacent rooms in case of indirect ventilation) is prohibited except in cases foreseen by rules in force and anyway the installation must be made in compliance with all specific safety measures mentioned in the rules and laws in force, even in case of modifications or additions.

Installation, first starting up, maintenance and servicing

All operations for installation, first starting up, maintenance, servicing and gas conversion **must be carried out by qualified technicians**, in accordance with the Norms and Laws in force.

Maintenance operations must be carried out in compliance with the manufacturer prescriptions, and in compliance with the laws and rules presently in force for what is not mentioned in this handbook; we advice to perform them at least once a year to maintain the boiler's performance.

Appliance booklet or central plant booklet

All appliances must have an appliance booklet (for outputs less or equal 35 kW) or a central plant booklet (for outputs more than 35 kW). All maintenance and servicing operations and combustion checks must be written on the booklet, together with the name of the person responsible for servicing.

Combustion checking

Combustion checking consists of a control of the boiler efficiency. Boilers that, after the checking, will have efficiency rates lower than the ones required and not changeable with suitable adjustments (that must be performed by qualified technicians), must be replaced.

Boiler operation and servicing

The user (owner or tenant of the flat where the boiler is installed) or the administrator of the block of flats (in case of a central heating system) are responsible for the appliance operation and servicing; they can both transfer the responsibility of the servicing and eventually of the operation to another person, which must be a qualified technician as indicated by the Laws. Even if the user or the administrator decide to assume personally this responsibility, ordinary servicing of the warm air heater and combustion checks must be anyway carried out by a qualified technician



The front control panel

Pushbuttons




Stand-by / Functioning mode

At every press, the boiler cyclically switches its working mode. The current mode is displayed by the writing OFF (boiler in stand-by) or by the symbols:

.III + F = Winter;

F = Summer (DHW only);

.III = heating only.



00314 00



CH setting



To set the CH system temperature. If the Outdoor Sensor Kit was installed, see also "Outdoor Sensor Kit" on page 53.



DHW setting



To set the DHW temperature in the storage tank.



Press to reset the boiler in case of breakdown.

See further details in "Alarms - boiler block" on page 41.

Display - symbols enabled in this model and their description



CH – winter mode indication

If flashing, it means that the boiler is functioning in CH mode. See also the remark in the description of symbol F.



Burner ON


It indicates the presence of the flame in the burner.



DHW mode indication

If flashing, it means that the boiler is functioning to heat the water in the storage tank.



If both .III and F symbols flash at the same time, a Technician-reserved function has been activated. In this case, turn immediately the boiler off - and then turn it on again - by means of the button .

56

Two digit display under the symbol .III'

Normally, it displays the **CH flow** temperature, i.e the temperature of the liquid on boiler's outlet that is sent to the CH system.

88

During the CH temperature setting (by pressing the buttons **+ .III'** and **- .III'**), it shows the **temperature value changing**; in case of **alarm** it displays "E"; during the **setting (reserved to the Technician)** it displays the chosen **parameter ID number** (see "PCB parameters settings (technician menu)" on page 32).

843

Three digit display under the symbol F

Normally, it displays the temperature of the hot water in the storage. When the boiler is in stand-by mode, it displays **OFF** .

0FF

During the DHW temperature setting (by pressing the buttons **+ F** and **- F**), it shows the **temperature value changing**; in case of **alarm** it displays the **ID number** of the alarm (see "Alarms - boiler block" on page 41); during the **setting (reserved to the Technician)** it displays the **value** of the chosen **parameter**.

RESET

It appears when the boiler is locked or anyway is present an error that the user could manage. See "Alarms - boiler block" on page 41 to identify the problem and the relevant actions to be carried out.

SERVICE

It appears when the boiler has detected an error (mainly a fault) that has to be managed by the Technician. The User can anyway see "Alarms - boiler block" on page 41 to get information about and the eventual actions to be carried out.



It informs that the outdoor probe (accessories) is installed.

***Note:** In this case the CH system temperature is automatically set and so the use of buttons **+ .III'** and **- .III'** is different from the standard way: for deeper details rely on kit instruction and see "Outdoor Sensor Kit" on page 53.*

Commands on the lower side


- 1 System pressure gauge
- 2 GAS cock

Commands outside the boiler

Externally the boiler, suitably positioned in the building (generally by the installer or by the electrician), some devices that the user should access to, are present. The presence and the characteristics of these devices are prescribed by the regulation in force.

Two-pole switch: it is located usually close to the boiler and it's for electrically insulating the boiler itself from the domestic mains power supply network. It is useful to disconnect the boiler from the electrical supply, e.g. during inactivity periods (see "Safety shut off" on page 11) or in some cases of alarm (see "Alarms - boiler block" on page 41).

Room thermostat: it commands electrically the boiler to activate or deactivate the heating system, in order to keep the room temperature (detected by a sensor) within a value set by the user, Regula-



tion in force prescribe its positioning, the temperature limits within the user can adjust it and the periods of heating.

Remark: an optional, original Remote Control kit is available (see "Remote Control Kit" on page 54 for information) or a cutting-edge chronothermostat kit featuring weekly programming of various temperature levels and other special functions. Also **wireless** and **GSM controlled** versions are available.

Faucet or valve for filling the system: a device must be foreseen, by the installer, to fill and pressurize the system. Basically it is a faucet or valve, possibly near the boiler, connected to the fresh water source. If, however, the plant is to be filled with heat exchanger fluid (eg anti-freeze solution) instead of water, it must be equipped with a hose plug or other fitting suitable for supply, under pressure, the system with such liquid (see also "Heating system filling and pressuring" on page 19).

Commands related to Domestic Hot Water

By the point of view of the domestic hot water, the boiler is designed to be implemented in a system with a domestic hot water storage tank, usually combined with a solar system, that on its turn is normally equipped with suitable commands and indicators to manage the hot water sent to the users.

Only when a storage temperature probe, connected directly to the boiler, is present, the setting of the DHW temperature, by means of the buttons **+F** and **-F**, determinates the temperature to which the water in the storage is heated*. If no temperature adjustment devices, downstream the storage, are installed, the buttons **+F** and **-F** adjust the temperature of the water to the user. Otherwise, this setting will affect only the maximum available temperature* and on the "duration" of the availability of hot water. (* in absence of heat input from external systems, e.g. solar). More complex systems can manage directly both the storage temperature (by forcing the boiler to heat the storage, if required) and the temperature to the user. **See the documentation supplied with the system** or ask for information to the installer or to the designer.

(i) **A high storage temperature increase the limestone scale of the storage.** Also gas consumption depends on the set temperature, aside from the quality of the storage thermal insulation.

Remark: Because of the thermal dissipation along the pipings, it could be necessary a certain time before the temperature of the water out of the faucet gets stabilized.

















Typical use

Preliminary operations

- ▶ Be sure the gas cock **3** is opened.
- ▶ Be sure the boiler is electrically powered and set in **OFF**: only **OFF** has to be displayed on the screen.
- ▶ Make sure, by the gauge **1** that the **cold-system temperature is always within 0.5 and 1.5 Bar (optimal: 1±1.5 Bar)**. When the pressure **drops below 0.5 Bar**, the boiler **stops working**. In this case, use the system filling device up to restore, on the gauge, the pressure of **1.0 Bar (max 1.5 Bar)**.

(i) The system pressure raises with the temperature: a too high initial cold-system pressure could lead to **water drain from the 3 Bar safety valve** after the system heating-up.


Boiler activation















- ▶ Press the button :
 - once to set the boiler in Summer mode only (DHW only). Summer mode is recognizable by the only symbol presence  on the display and not by the symbol presence ;
 - pressing twice to set the boiler in Winter mode for making the boiler working both for CH and DHW. Winter mode is recognizable by the both symbols presence  and  on the display;
 - pressing a third time to set the boiler in Heating Only mode, i.e. for making the boiler working for CH only, leaving the DHW production OFF. Heating Only mode is recognizable by the presence of only symbol  on the display;
 - at each press of the button , the boiler cyclically switches from **OFF** to Summer , to Winter  +  and to Heating Only mode .
- ▶ On Winter mode  +  or Heating Only mode , when room thermostat demands for heating, the burner fires up and thanks to the water flow the heating gets transferred to the heaters of the building.
- ▶ On Winter mode  + , in case of contemporary demand of heating from both DHW storage and CH, the DHW demand has the priority till the demand finish. Usually, as DHW does not last for long, this priority does not affect the CH efficiency in the system.

Temperature adjustment

Note: correct adjustment leads to creating the conditions for energy saving.


Note: if a Low Temperature Kit or an Outdoor Probe Kit are installed, refer to the relevant documentation for what concerns the heating system temperature adjustment.

Note: don't make confusion between the heating system temperature  here described, with the temperature of the room set on the Room Thermostat.

- ▶ **Heating system adjustment:** by using the buttons   and  , the setting of the heating system temperature is made (the value, during the adjustment, is shown on the display under the symbol ). Generally, in the deep cold season and/or with poor building thermal insulation (or if you notice that the burner stays on for a long time, but the room temperature rises too slowly) prefer higher settings. On the contrary, if you notice that the room temperature exceeds too much, for thermal inertia, the value set on the room temperature, it's appropriate to decrease the system temperature. **When the optional Outdoor Temperature Probe Kit is installed, the system temperature is automatically managed and the use of the buttons   and   is different:** for details, see also "Outdoor Sensor Kit" on page 53.
- ▶ **Domestic hot water adjustment:** the buttons   and   set the temperature of the water in the DHW storage (the value, during the adjustment, is shown on the display under the symbol ). See also "Commands related to Domestic Hot Water" on page 9 about the DHW temperature.

Anti-Legionella function

With regular periodicity the boiler, in Summer or Winter mode, automatically provides for the heating of the water in the storage, so as to destroy eventual bacteria (especially *Legionella spp.*) which form in quiet warm water.

Remark: the Anti-Legionella function is not active when the boiler is set in **OFF** or in Heating only  mode.

Incidental malfunctioning






Avoid performing personally any intervention that are job of the technician, for example the ones on the electrical circuits, on hydraulic system or on the gas system, and whatever other operation that's not mentioned in this "User Guide" section and expressly allowed to the User. Always address yourselves to qualified personnel.

Boilers must be always equipped with original accessories only.

ITALTHERM S.p.A. is not responsible for damages caused by the incorrect, wrong or unreasonable use of not original materials.

The burner doesn't turn on

- ▶ if the room thermostat (or programmable room thermostat, or similar) is installed, check that it is really requiring the room heating;
- ▶ be sure the boiler is set on winter  +  or summer  mode (not in **OFF**). The reference symbols must be shown on the display (see "The front control panel" on page 7);
- ▶ in case the display shows **RESET** or **SERVICE** , or in case the boiler seems to be working in an inappropriate way, see "Alarms - boiler block" on page 41;
- ▶ check on the gauge that the boiler pressure is correct (1÷1.5 Bar **in a cold state**) or at least **not below 0.5 Bar**.

Shortage of domestic hot water production

- ▶ check the DHW temperature is not set on a too low value: if so, adjust it (see "Temperature adjustment" on page 10);
- ▶ call a qualified technician to check gas valve regulation;
- ▶ call a qualified technician to check, and eventually clean, the coil of the DHW storage.



Remark: where the water hardness value is too high, it is suggested the installation of a softening device, in order to prevent the limestone precipitation; this operation avoids a frequent cleaning of the coil of the DHW storage.

Boiler inactivity

The effects of the periods of inactivity can be relevant in particular situations such as in flats used only for some months per year, most of all in cold places.

The user will have to decide to put the boiler in the **SAFETY SHUT OFF state** disconnecting all the supplies, or to **leave it on OFF mode (but electrically supplied) in order to let the Anti Frost Function work**. When there is the possibility of freezing it is convenient to chose between the advantages and the disadvantages of the SAFETY SHUT OFF and of the Stand By/Anti Freezing Way.

Safety shut off

- ▶ Turn off the general switch on the Electrical Supply Line of the Boiler;
- ▶ Close the Gas Tap;



When it is expected that the temperature is going to decrease under 0°C, call a technician to do the following:

- Fill the system, included the primary circuit of the storage unit and the relevant coil, with an anti-freezing solution (unless the system was already filled with said solution) otherwise it must be completely emptied. Notice that if it had been necessary to restore the pressure (because of

possible loss) in an heating system already filled with an Anti freezing solution, the concentration of the solution could have decreased and it could not guarantee the Anti freezing Protection.

- Let the condensate collector syphon be emptied unscrewing its inferior cap.
- completely empty the hot and cold sanitary water system, including the sanitary circuit and the DHW storage.

Remark: the boiler is equipped with a system which protects the main components from the exceptional cases of mechanical lock, due to the inactivity in presence of water and scale. The anti-locking function can't work in Safety shut off mode, because of the lack of electrical supply.

- (i)** Before re-igniting the boiler, have a technician check that the pump is not blocked due to inactivity (for the technician: unscrew the plug in the centre of the cap to access the rotor shaft and turn it with a screwdriver or other suitable tool).

Stand-by mode with anti-frost & anti-locking function

When the boiler is left in **OFF** mode during a period of inactivity, it will be protected against freezing by several functions provided in the electronic controller, which heat the parts involved when the temperature falls below factory set values.

The anti-frost heating is accomplished by turning on the burner and pump.

In addition, when the boiler is in stand-by, it periodically activates the main internal components to avoid rare cases of blockage due to inactivity in the presence of water and lime. This can also occur when the boiler is locked (red lamp on) provided that the system pressure is correct.

In order for these systems to be active:

- the boiler must be receiving gas and electricity;
- boiler must be left on **OFF** mode (**OFF** shown on the display);
- system pressure must be correct (1±1.5 bar in a cold state, minimum 0.5 bar)

In case of gas supply failure, or if the boiler locks for other reasons (the display shows **RESET** or **SERVICE**) the burner won't turn on. Nevertheless, any time it is possible, the pump will work, making the water circulate in the system and reducing in this way the possibility of freezing.



- (i)** **ATTENTION:** the anti-frost protections cannot intervene in the absence of electricity. If you anticipate this possibility, we recommend you add a good brand of anti-freeze to the heating system, following the producer's instructions.

We recommend to ask directly the installer/technician about the type of antifreeze product put in the heating system during installation.

When the power comes back on, the boiler will check the temperature measured by the two probes and, if it suspects freezing verified by a particular automatic control cycle, alarm 39 will be triggered. For more details, see the relative description in the paragraph "Alarms - boiler block" on page 41.

- (i)** We recommend that you completely empty the hot and cold sanitary water system, including the sanitary circuit and the DHW storage. The anti-frost function does not protect the sanitary circuit outside the boiler.

“Ambient Anti-Frost” Function

Note: if you want to use the “Ambient Anti-Frost” function that is often available in common room thermostats or chronothermostats, it is necessary **NOT to leave the boiler in OFF mode** but in a mode that allows the heating, e.g. Heating Only mode  (that saves from useless heating of the DHW storage, although keeping its anti-freeze function active), or in Winter  mode.



The “Ambient Anti-Frost” function does not protect the sanitary circuit outside the boiler and, especially, in areas where the heating system doesn’t reach. For this reason, we recommend that you empty the cold and hot sanitary water, including the DHW storage, from the parts of the system that are at risk of freezing.

Installation



Law and regulation prescriptions for the installer



Always comply with national and/or local regulation about BOILER INSTALLATION.

Always comply with national and/or local regulation about WORK SAFETY of Personnel in charge of installation.

Characteristics of the room: as this boiler has an heat output lower than 35 kW (about 30000 Kcal/h), it is not required to install the appliance in a dedicated room, provided that the room complies with the regulation in force and that all installation rules assuring a safe and regular gas boiler operation, are strictly respected.




Permanent ventilation of the installation room is mandatory and extremely important when a boiler with air draught from the installation room (B... appliance type) is installed. Ventilation must be made and sized in compliance with Laws and Rules in force.

Presence of other appliances: the presence of other appliances (especially if they interfere with the boiler draught) can be forbidden by the regulation in force or can require modifications (e.g. the enlargement of the ventilation opening or the making of new ones).

Instructing the user: at the end of the installation, the installer must:



- explain the operation of the boiler and its safety devices to the user;
- give this user this booklet and the documentation within his/her competence, duly filled in where required.



Dimensions and connections



Pump capacity diagram

(i) See also "Pump settings" on page 41.





Warnings for the installation of optional kits or special systems

Floor heating system

(i) The safety thermostat(s) that protects the floor against overheating (that could damage the cladding, the structure or the system itself) must be installed on the flow starting end of the serpentine embedded in the floor itself. It should not be installed on the system flow pipe in proximity of the boiler, otherwise frequent and unjustified boiler locks, caused by its triggering, are possible.

Specifications for intake air

Air must be withdrawn from places free of pollutant (like fluorine, chlorine, sulfur, ammonia, alkaline or similar agents). In the event of installation of the boiler in atmospheres with not negligible presence of aggressive chemical substances (e.g. hairdressing salons, laundries) we recommend to foresee the air intake from outdoor, choosing the type C installation, through which the supply of chemical-free combustion air is ensured.

Also make sure that the combustion air is not supplied through chimneys that were previously used with oil-fired boilers or other heating appliances.

Domestic water supply characteristics

The cold water inlet pressure must be lower than 6 Bar. Besides, for an optimal boiler functioning, water pressure **should be more than 1 Bar.** A lower pressure could make difficult to restore correctly the pressure the heating system.

(i) In case of higher pressure **it is indispensable to install a PRESSURE REDUCER** upstream the boiler.

The cleaning frequency of the storage coil depends on the water supply hardness. If the water hardness is more than 25° fr it's required to install a softener to bring the hardness below that value.

Besides, the presence of solid residuals or impurities in the water (for example in case of new systems) could compromise the correct functioning of the boiler. For DHW production systems, the regulation in force prescribes a safety filter to protect the systems.

(i) The condensing burner/exchanger assembly requires **particular characteristics for the heating system liquid**, more restrictive than the ones of the inlet domestic water. See the "Heating" section of the table "Technical data" on page 48.

Protection against freezing

Thanks to its antifreeze system, inner components could never reach a temperature lower than 5°C. This system is activated when the boiler is supplied by the electrical and gas lines, provided that the pressure in the heating system is correct.

(i) If some part(s) of the system external to the boiler (included the primary circuit of the storage unit and the relevant coil) could be subject to freezing risk, it is advisable to fill the heating circuit with, instead of water, an antifreeze liquid specific for heating systems, propylenic glycol based, following the instructions of its manufacturer. Pay attention to the correct product concentration: adding those substances to the heating water in incorrect dose could lead to the deformation of the seals and cause unusual noises during operation.

ITALTHERM S.p.A. will not be held responsible for consequent damages.


Instruct the User about the antifreeze function of the boiler and about the antifreeze product added in the heating system.

Outdoor installation in a partially protected place

This type of forced draught condensing boiler can be installed outdoor, but only in partially protected places.

The boiler minimum and maximum working temperatures are mentioned in the paragraph "Technical data" on page 48 and on the boiler data plate.

The materials used for the boiler installation, including the devices and/or the materials used for thermal insulation, should be so to **maintain their functionality** within the temperature range indicated on the data plate.





If the place where the boiler is located is converted **from outdoor to indoor** (e.g. veranda) it will be necessary to **verify the compliance** of the new configuration with the laws and rules in force, and to make the modifications required.

Positioning and fastening

Remark: A re-usable metal jig (**D** in the figure) can be ordered separately, so as to facilitate connections and fixing points positioning (when the original connection kit is used). **If the metal jig and/or the original connection kit are not used, refer to the paragraph "Dimensions and connections" on page 14 for the position of the connections directly on the boiler.**


- ▶ Locate the exact position of the boiler considering the sufficient clearances for maintenance and servicing: at least 50mm laterally and 300 mm on the lower side
- ▶ Choose the fastening/hooksing option among **A** or **B**, depending on the fixing devices used or already available if any (open hooks; wallplugs; "stud" type with nut).
- ▶ If the metal jig is used, hang it on the wall using the same fixing devices and the holes or slots **A** or **B**.
- ▶ Fix up the connections and all ducts for heating flow and return, storage coil flow and return, gas and electrical cables, predisposing them in the holes of the metal jig or, as an alternative, respecting the measures in the paragraph "Dimensions and connections" on page 14. The upper edge of boiler's body, used as a reference in the paragraph "Flue system types" on page 26, is represented by the dotted line **C** in the figure.



- **model 35 KR only:** pull upwards and remove the plastic blocks that hold the sides of the expansion vessel.



If the Storage Unit is not installed in the same moment of the boiler, remember to **close the Flow to Storage and Return from Storage** connections, to allow the filling and pressurization of the heating system.



- ▶ Remove the jig (if used) and hang the boiler to the fixing devices, using the chosen holes or slots **A** or **B**.
- ▶ **Remove the plastic caps** placed to close the hydraulic connections on the boiler.
- ▶ Proceed with the hydraulic, gas, electrical and flue connections following the instructions and warnings reported in the following paragraphs.

	Heating Flow (3/4")
	Flow to storage coil (3/4")
GAS	Gas (1/2")
	Return from storage coil (3/4")
	Heating Return (3/4")
	Electrical Power Supply
TA	Room Thermostat



The connections of the boiler are engineered to fit plain couplings with screw ring, interposing a plain gasket of suitable size and material, that ensure a reliable seal even without excessive tightening force. They are NOT suitable for hemp, teflon tape or similar materials

Hydraulic system (DHW and heating)



Make sure that the hydraulic and heating systems ducts **are not used as earth connections of the electrical system**. They are absolutely NOT SUITABLE for such a use. Besides: they don't guarantee the earth dispersion; in case of electrical fault they could generate a fulguration risk; there could take place galvanic currents in the pipings and consequent corrosion and hydraulic leaks.

Advices and suggestions to avoid vibrations and noises in the system

- ▶ Do not use pipes with reduced diameters;
- ▶ Do not use bends with small radius and reductions of important sections.

Cleaning and preservation of the systems

The efficiency, the reliability and the safety of the boilers, as all generic thermal systems and components, depend strictly on the features of the water that supply them and on their treatment.

A proper treatment of the water improves the protection of the systems against corrosions (and therefore perforations, noise, leaks, etc.) and limestone incrustations that drastically reduce the efficiency of the thermal exchange (consider that 1 mm of limestone incrustations reduces of 18% the thermal exchange of the heating element on which it has been formed).

ITALTHERM guarantees its products only if the characteristics of the water comply with UNI 8065, reported also in laws on energy saving.

(i) Thoroughly wash the heating system with water, before connecting the boiler. This will eliminate residual like welding drops, slag, hemp, mastic, mud, rust and other dirt from pipes and radiators. Otherwise, these substances could enter the boiler and damage the internal components (pump etc.).

- ▶ **In case of old or very dirty systems, to wash them use specific, proven efficiency products**, in the suitable quantity and following the instructions of its manufacturer.
- ▶ If the water on boiler inlet is harder than 25° fr, it's required to install a softener to bring the hardness below that value, as required by the reference regulation.
- ▶ For floor system and generally all low temperature systems, the water treatment product must have filming action (protection against corrosion and incrustation) and action against bacteria and algae.

Heating system

- ▶ Connect the safety evacuation ducts of the boiler to an evacuation funnel. If safety valves are not connected to an evacuation device, their intervention could flood the room. The manufacturer cannot be held responsible for any damage arising from that situation.

Piping between the boiler and the storage unit

Link the connection on the boiler identified by **MB** (flow to storage) to the **MB** connection of the Storage Unit, and the **RB** (return from storage) connection of the boiler to the **RB** connection of the Storage Unit.

(i) **Swapping the flow and return connections could lead to malfunctions.**
Warning: If a recirculation pump is installed, install a check valve.

Condense drain

Insert the flexible pipe of condense outlet inside the outlet funnel (or other inspectable connection device) properly installed for this purpose, or in the outlet funnel of the safety valve, in case of the above mentioned outlet is able to receive the acid liquids of the condense as foreseen by the norms in force in matter of condensing boilers.


(i) Requirements for the condense drain system:

- It must be made in a way that doesn't allow the condense freezing or other blockages, and it must not allow modifications or obstructions
- before the first starting up of the appliance, ensure that the condense can be correctly drained
- if the intended use of the building unit foresaw the installation of a condensate neutralization system, make sure that you have the relevant instructions for use, cleaning and maintenance

Heating system filling and pressuring

Once all system connections have been carried out, proceed with system filling. This operation should be made with care, respecting the following steps:

- ▶ Open the radiators venting devices;
- ▶ Check that the plug of the automatic air vent, incorporated in the boiler circulator, is unscrewed: if not, unscrew it and leave it unscrewed, even afterwards, for normal operation;
- ▶ Locate the system filling device, foreseen externally to the boiler, and proceed depending on its type:
 - filling from aqueduct: open it and let water flow in the system
 - filling with anti-freeze solution: pump in the solution and pressurize the system.
- ▶ Check the correct functioning of automatic venting devices, eventually installed on the heating system and/or on the storage coil circuit;
- ▶ Close the radiators venting devices as soon as water or anti-freeze solution flows out of them;
- ▶ If the storage coil or the relevant circuit were equipped with manual venting valves, use them to purge the residual air from them;
- ▶ Make sure, by reading the pressure gauge **1**, that the pressure reaches the optimal value of **1.0 bar (max 1.5 bar)**;
- ▶ Close the filling device and bleed each radiator again;
- ▶ Repeat the venting and pressurization operations until the air is completely purged from the system.



DHW storage tank filling

- ▶ Fill the DHW storage tank (on storage unit):
 - open one of the hot water taps in the DHW system;
 - gradually open the hand valve installed on the cold water inlet of the storage unit;
 - when only water flows out of the tap, close it.

Gas connection

Due to various installation possibilities, the gas cock **3** supplied with the original Connections Kit has a simple male $\varnothing \frac{1}{2}$ " connection, facing the rear of the boiler. *The gas pipe 4, upstream the gas cock 3, should be supplied by the installer.*



While connecting the gas inlet of the boiler to the gas supply piping, it is **MANDATORY** to insert a **PLAIN GASKET**, whose dimensions and material must be adequate. Connection is **NOT** suitable for hemp, teflon strip or similar materials. Because of the type of fitting, the use of those materials does not make the suitable seal with consequent gas leaks!



This boiler is designed and prepared to be supplied with Natural Gas G20 (Methane). It can be set, just by means of electronic settings, but **always by a qualified technician, to operate with Commercial Propane G31.**

It must never be used with Butane gas G30 (that can be present, pure or mixed with Propane G31, in the portable gas bottles for cookers) **therefore, if the boiler is prepared for operation with commercial Propane G31, we recommend to inform the supplier of the fuel, for example, by applying a suitable warning on the gas tank** or in its immediate vicinity, so that it is visible to the employee when it is being refilled.



Using Propane gas G31, it is **absolutely necessary to install a pressure reducer upstream the boiler. Failure to do this, the gas valve of the boiler will get damaged. The inlet gas pressure must be compliant with the one specified in "Technical data" on page 48.**



The gas connection, as generally the boiler installation, must be done by qualified personnel as prescribed by the regulation in force, because a faulty gas connection could lead to fire, explosion and other very serious damages to persons, animals and objects. The manufacturer cannot be held responsible for any damage arising from that situation.

► Verify what follows:

- cleaning of all system gas pipes in order to avoid the presence of work residuals that could compromise the correct boiler functioning;
- gas line and ramp conformity with laws and rules currently in force;
- internal and external tightness of the gas system and connections;
- supply pipe must have a section greater than or equal to the boiler one;
- supply gas must correspond to the one for which the boiler has been set: otherwise, it's mandatory to ask to qualified personnel to set the boiler for the correct gas type;
- an interception valve must be installed upstream the appliance.

► Open the meter valve and purge the air that is inside the system pipes (including all the appliances).

Electrical connections of the boiler



The link of the room thermostat works with a safety extra low voltage (SELV); connect it to the voltage free contacts of the room thermostat/chronothermostat. **On NO account must any electrical voltage be applied** to these terminals.



All low-voltage wirings (e.g. Room Thermostat or Chronothermostat for trade) must be kept separate from power supply cables, as to avoid boiler malfunctioning due to electrical noise. It is advisable to use separate tubes for them.



During the connection of cables from the boiler, make sure that they are not tight and make a slack that allows the control panel to be fully tilted.

The boiler must be connected to a 220÷240V - 50Hz electrical power supply. In any case, the power supply voltage must be within the range -15% ... +10% from the nominal value (230V); otherwise it may cause malfunctions or failures. It is necessary to respect the polarities L-N (Live L=brown; - Neutral N=blue) - otherwise the boiler may not work - and the earth connection (yellow-green cable).



Place upstream the boiler a bipolar switch in compliance with the regulation currently in force. The installation must be made complying the regulation currently in force and generally with the standard craft rules.

For the general electrical supply of the appliance the bipolar switch should be used. The use of adaptors, multiple taps and extensions is not allowed.

If the supply cable must be replaced, use one of the following cable types: H05VVf or H05-VVH2-F. **It is mandatory the earth connection in accordance with the rules actually in force.** To replace the cable, open the control panel cover, unlock its fastening device and disconnect it from the terminals. Install the new cable proceeding in the reverse way. When connecting the cable to the boiler, it's mandatory:

- to leave the Earth wire about 2 cm longer than the other (Live and Neutral) wires;
- to lock the cable upstream the terminals by means of the suitable fastening device.



Electrical safety of the appliance is only achieved when it is well connected to an efficient earthing system, executed as indicated by the safety rules actually in force.

A qualified technician must check that the electrical system is in line with the maximum power allowed by the boiler, indicated on the data plate, with particular attention to the cables section.

(i) ITALTHERM S.p.A. declines any responsibility for damages to persons, animals or things caused by the faulty or missing connection of the boiler earthing and by failure to comply with the rules.

Electrical connection between the boiler and the storage unit



Don't connect the storage temperature sensor terminals to the power supply or to live wires.

As shown in "Electrical diagram" on page 51, the boiler has two different inputs for the electrical connections to the storage unit:

STB: input for a *storage temperature sensor*: the boiler reads the storage temperature and, if necessary, switches to storage heating mode to keep its temperature around the value set by means of the buttons **+** and **-**. Even if the storage unit is NOT supplied by Italtherm, it's necessary to **use the original temperature sensor kit** (NTC R=10 kOhm at 25°C, β=3435). Only if the **STB input is used**, it's necessary to **remove the factory-installed resistor**, that **otherwise must be left installed**.

(i) The cabling between the storage temperature sensor STB and the boiler must pass in a sheath separate from the ones containing supply cables. In every case, the maximum length for a 2 x 0.5mm² cable is 30m.

AUX: auxiliary input for *storage thermostat (TB)* or *solar DHW heating request*: when the contact is closed, the boiler work is forced in DHW storage heating, until it opens (or up to the reaching of the max boiler temperature). To be used if the storage has a thermostatic temperature control (even manually adjustable) or in connection with a solar system, to allow it to require the heating of the storage when the solar heat contribution is insufficient.

Remark: to configure the *AUX input for the storage thermostat*, the *Parameter 46* has to be set to value 1 (see also page 36).

Remark: if both inputs are used, functionally **the TB has the priority on the STB**, i.e. if TB is closed, the storage gets heated even if the temperature measured by STB is higher than the set one.

Flue systems

Intake/outlet flange

The boiler is equipped with a flange for connecting inlet and outlet flues pipes; this flange has been studied for collecting rain/water that may creep into the inlet pipe and for avoiding that rain reaches the burner's fan.

Rain/water collected is conveyed, thanks to silicon tube, to internal siphon for draining

On the flange there are:

- ▶ outlet pipe connection **1**, both coaxial and separate configurations;
- ▶ inlet for coaxial configuration **2**;
- ▶ inlet pipe connection for separate configuration **3** (remove the cap only if you are installing the separate configuration);
- ▶ prearrangement **4** for an accessory not provided with this model (to be NOT opened).


(i) Pay attention to only connect **inlet separate** pipe to **connection 3**, **instead of prearrangement 4**. This wrong connection could allow rain/water going to fan and burner, damaging it.

General indications

To grant the functionality and efficiency of the appliance it is indispensable to realize intake and outlet ducts using flue accessories specific for condensing boilers.

(i) **WARNING:** the specific flue accessories components for condensing boilers, especially the parts which are in touch with the flues outlet, are so projected because they are made with **plastic materials acids resistant**, but because of their nature, **they are not suitable to resist to the higher temperature** of the flues of the traditional boilers. So it is **not possible to use traditional flue components for the outlet ducts of the condensing boilers, neither vice versa**.

(i) When installing the pipes, we recommend lubricating the inside of their gaskets exclusively with **silicone** lubricants since their material (EPDM peroxide) is not compatible with other types of oils or greases



If it is possible, we recommend to foresee (referring to the direction of the air/flue, see examples on page 24) an upwards slope for all the intake and outlet ducts, in order to:

- ▶ **PREVENT** the water or dust or other objects entrance inside the **INTAKE** duct. In case of coaxial ducts, use the special horizontal terminal, which is especially built to respect these slopes only for the first length of the intake duct;
- ▶ **FACILITATE**, in the **OUTLET** duct, the flowing back of the condense towards the combustion chamber, which is built to work in these conditions and to discharge the condense. If so it is not possible, or if there are some points where the condense stagnates inside the outlet duct and if it is not possible to avoid this through a modification of the slope of the ducts, these points must be drained using the specific kit of condense collector (consult the commercial catalogues of the original accessories), and ducting the condense formed towards the outlet duct as foreseen by the norms in force in matter of condensing boilers.

Air intake and flue outlet terminals should be protected by suitable approved flue accessories, to avoid environmental elements penetration.

Carefully follow the indications foreseen by the specific laws in force.

Respect the minimum and maximum flue length prescribed (see "Flue system types" on page 26).

In case of flue outlet on wall, the positions and the distances prescribed by the regulation must be respected.


The **outlet duct is the assembly of components that connect the boiler to the point where the flues are discharged**. The outlet can be directly outdoor only in the case foreseen by the law in force and using at the end of the outlet duct a specific terminal.

In case you foreseen to discharge the combustion products through a **chimney** (for single user) or a **common flue** (for multiple users) the part of the evacuation system (the chimney or the flue) to which the outlet duct of the condensing boilers is connected, **must be declared suitable for this purpose by its producer**. In case of common chimney, keep in mind the laws in force regarding the typologies and rates of users.

Don't lean the flue pipe into the chimney, but stop it before the inner surface of the chimney. The axis of the flue pipe must intersect the axis of the chimney or of the flue duct.

In general situations the **evacuation systems** of the combustion products **must be properly declared suitable from the producer of the same system** for wet functioning, **or must be supplied by the appliance's producer** (gas boiler).



If the chimney (or the flue) were not suitable, it would be indispensable, to use it, to canalise it through specific ducts, so for example through the original flue accessories.



Examples of installation of intake and outlet ducts


We give you some correct and wrong examples of installation of intake and outlet ducts for condensing boilers (the slope are voluntarily represented in an exaggerated way).

A = Intake; **S** = Outlet. **1**: the most functional and economic solution is to let the condense come back towards the boiler**. **2-3**: if an obstacle prevents to install the ducts upwards, it is necessary to install condense collectors, so as to avoid stagnations. **4**: if, respect to the air flow, the slope of the intake ducts is upwards (for their all length or at least only for the external tract) this is sufficient to prevent the rain water to reach the burner's fan*. **5**: so the intake must not be downwards*. **6**: do not let the condense go out from the flue outlet terminal. **7**: the coaxial intake/outlet duct must be installed so as the flues are upwards, and so the condense discharge itself towards the boiler. The terminal tract with intake head and outside with an outlet out axis must be horizontal placed and it is equipped with ribs which prevents the water entrance* in the external intake duct. The internal outlet duct is upwards and canalises the condense in the correct direction.



* Inlet/outlet flange has been designed to ensure a discharge of small and occasional amount of water, which may creep into inlet pipe.

** In some cases, the flow of the condense towards the boiler is not allowed: see "Allowed flue types" on page 27.



00045.00

Dimensioning the intake and outlet ducts

In the following table, all the characteristic losses of load of the original fume venting accessories, expressed as equivalence in meters (m) are listed.


(i) If additional, original flue accessories, aside from the ones pictured, are used, the total system length should be calculated considering the sum of the equivalent characteristic losses of load, expressed in meters in the following table.

In the case where pipes are installed with non-original accessories (this is allowed by the boiler's C6 type-approval), **but, in any case, absolutely certified for condensation**, the installer must consider the losses of load specified by the manufacturer of these accessories, dimensioning the suction and discharge system so that the total loss of load (expressed in Pa) is between the head loss values of the boiler fan specified in the paragraph "Technical data" on page 48.

Original accessories for all separated systems (advised even for type C6):	Ø60mm	Ø80mm
Connector from boiler to Ø80mm intake pipe or to adapter from Ø80mm to Ø60mm	0.3 m - 2 Pa	0.8 m - 2 Pa
Connector from boiler to Ø80mm outlet pipe or to adapter from Ø80mm to Ø60mm	0.7 m - 5 Pa	2.0 m - 5 Pa
Separate system (original accessories):		
Adapter from Ø80mm to Ø60mm on intake	0.4 m	—
Adapter from Ø80mm to Ø60mm on outlet	1.7 m	—
Linear section or extension, length 0.5m on intake	0.5 m	0.5 m
Linear section or extension, length 0.5m on outlet	0.5 m	0.5 m
Linear section or extension, length 1m on intake	0.9 m	0.9 m
Linear section or extension, length 1m on outlet	1 m	1 m
Linear section or extension, length 2m on intake	1.8 m	1.8 m
Linear section or extension, length 2m on outlet	2 m	2 m
90° bend on intake	1 m	1 m
90° bend on outlet	1.6 m	1.8 m
45° bend on intake	0.5 m	0.5 m
45° bend on outlet	0.8 m	0.9 m
Intake terminal section	1.4 m	1.6 m
Horizontal outlet terminal section	1.4 m	3.5 m
Vertical outlet terminal section	1.3 m	3.6 m
Original accessories for all coaxial systems (advised even for type C6):	Ø100/60mm	
Flanged coaxial connector (starting vertically)	0.2 m - 2 Pa	
Coaxial system (original accessories):		
Coaxial linear section or extension (length 1 m)	1 m	
90° coaxial bend	2 m	
45° coaxial bend	1.5 m	
Horizontal intake + outlet coaxial terminal	1.5 m	
Vertical intake + outlet coaxial terminal Ø125/80mm (with Ø100/60mm connector)	1 m	

Flue system types

Split pipe system (C₄₃, C₅₃, C₈₃, C₉₃ *)



Mod.	Original*** split pipe system Ø80mm	
	AS+SC min÷max (m)	SC max (m)
25 KR	1 ÷ 52	51
35 KR	1 ÷ 52	51


Mod.	Original*** split pipe system Ø60mm	
	AS+SC min÷max (m)	SC max (m)
25 KR	1 ÷ 16	15
35 KR	1 ÷ 16	15

* **Remark:** Split pipes allow to make also C₁₃ and C₃₃ flue systems.


** The dimensions on the duct axis are referred to the upper edge of the boiler's body, close to the mouth of the first 90° bend. The difference of level due to the slopes are not considered.

*** **IMPORTANT:** this table is referred to the original flue accessories. Using **non-original** flue accessories (certified for condensation, whose use is allowed by the boiler's C6-type certification) refer to paragraph "Dimensioning the intake and outlet ducts" on page 25.


Coaxial system (C₁₃, C₃₃)



Example of vertical coaxial system (C₃₃)




Put the outlet coaxial horizontal terminal with the outlet head **1** UPWARDS, as indicated in the picture, respecting the measures in the drawing. Check that the elastic sealing collar **2** is housed in the groove **4** and against the outside wall face **3**.



Example of horizontal coaxial system (C₁₃)

Mod.	Original*** coaxial system Ø60/100 mm	
	LCO min÷max (m)	LCV min÷max (m)
25 KR	1 ÷ 10	1 ÷ 12
35 KR	1 ÷ 8	1 ÷ 10

Allowed flue types



The flue duct and its connection to the chimney should be made in compliance to National and Local Regulation in force. – It's mandatory to use ducts that resist to temperature, condense, mechanical stress, and that are tight. – Not insulated flue ducts potentially lead to dangerous situations.

Air inlet from the room and flue outlet outside.

B23
B23P

REMARK: air inlet opening ($6 \text{ cm}^2 \times \text{kW}$).

...P: flue system designed to work at positive pressure.

B53
B53P

Same as B23 - B23P but flue system supplied with the appliance.

C13

Coaxial system, to wall. Ducts can start separate from the boiler, but outlets must be coaxial or close each other (within 50 cm) as to be subject to similar wind conditions.

C33

Coaxial system, to roof. Ducts can start separate from the boiler, but outlets must be coaxial or close each other (within 50 cm) as to be subject to similar wind conditions.

C43

Separated outlet and inlet, in shared chimneys subjected to similar wind conditions (natural draught chimney). **The condense flow towards the appliance is not allowed.**

C53

Separated outlet and inlet, to wall or roof or anyway to zones with different pressure.

REMARK: outlet and inlet must never be placed on opposite walls.

C63

Some outlet and inlet types (see "Technical data" on page 48) that can be made by using ducts traded and certified separately.

C83

Outlet in single or shared chimney and inlet from wall. **The condense flow towards the appliance is not allowed.**

Separated outlet and inlet, in shared chimney.

C93

Cavediums dimensions must ensure a minimum interspace between the outer wall of the chimney and the inner wall of cavedium:

- 30 mm for circular section cavediums
- 20 mm for squared section cavediums



WARNING: Hereby described operation can be performed by qualified technicians only.



When regulation/measuring is over, remember to verify the absent of gas leakages. Do not use free flames to detect gas leakages



The gas valve, exception the PIN plug and the upwards connections, works in NEGATIVE PRES-SURE. We do not recommend to use products for the detection of the gas leakages where not expressly indicated, because these products could penetrate inside the gas valve disturbing its normal functioning.



The siphon is an integral part of the combustion system and it's necessary to check its seal during every technical intervention on the boiler. Verify that both caps (upper and lower) are properly and completely screwed.



Verify that the combustion products do not go out from the outlet of the condense.



The condense syphon trap of the boiler is equipped with a special device which closes when dry. Anyway, the seal is guaranteed only when the syphon trap is filled with liquid. So, at the end of the first firing / commissioning operation, it is recommended to check that the syphon trap contains liquid, e.g. checking that liquid exits the condense drain of the boiler.



Before switching on the boiler, **make sure that the circulating pump is not blocked** due to inactivity: in the middle of the cap there is a hole (should there be a cap, remove it) that gives access to the rotor shaft; **push and turn it using a suitable tool**, usually a "Phillips" screwdriver.



During the commissioning of the **new boiler**, it is necessary to **run the burner for 30 minutes before checking the combustion** because, in that period of time, any residual fabrication vapours could cause false results in the combustion products analysis.

***Remark:** during the first 10 minutes of electrical power supply, the re-ignition delay in heating mode might be nil.*

- *The ignition electronics does several ignition attempts, to avoid blocking the boiler when the ignition fails sporadically.*
- *When the gas supply pipe is filled with air (e.g. in case of new installation) it may be necessary to repeat the ignition cycle several times.*
- *The boiler is factory regulated and tested. Anyway it's advisable, during the commissioning, to check that the regulation is correct.*

First starting up

The first ignition operations consist in verifying the correct installation and functioning, and in the eventual regulations which are necessary:

- ▶ verify that the data of the plate correspond to those of the net supply (electrical, water, gas);
- ▶ verify the absence of the gas leakages from the connections upwards the boiler;
- ▶ verify the proper realization and the efficiency of all the boiler connections (water, gas, heating system and electrical system);
- ▶ verify the presence of the permanent air/ventilation outlets, correctly dimensioned and working, as foreseen by the National and Local laws depending on the appliances installed;

- ▶ verify that the evacuation flue duct corresponds to the National and Local laws and that it is in good and efficient conditions;
- ▶ verify the correct functioning of the system of the outlet condense, also in the external parts of the boilers, i.e. the eventual condense collector installed on the flue outlet: verify that the liquid flow is not obstructed and that there are not inlets of gaseous combustion products inside the system itself;
- ▶ verify that the passage of the air burning and the evacuations of the flues and of the condense will be made correctly accordingly to National and Local laws in force;
- ▶ verify that the conditions for the air ventilation are granted, in case of a boiler placed inside a piece of furniture;
- ▶ vent the primary exchanger, proceeding as described in the paragraph "Venting the primary exchanger" on page 31;
- ▶ verify and, if necessary, change the boiler electronic settings to adapt its work to particular system requirements (see "Main boiler parameters (PC)" on page 33);

(i) Before turning on the boiler, verify that the pump is not blocked due to inactivity: unscrew the cap located at the centre of the pump's body, locate the rotor shaft behind the cap and turn it manually using a screwdriver or other suitable tool.

- ▶ verify that the combustion is correctly regulated: go on in this chapter as described in the paragraph "Combustion test" on page 36;

(i) During the first ignition of the brand new boiler, it is necessary that burner works for at least 30 minutes, before performing combustion checks. During this time, the fumes of the eventual residual manufacturing materials are produced, and they could alter the measured values.

- ▶ verify the correct functioning of the boiler in heating and domestic hot water version;
- ▶ fill in the foreseen documentation and leave to the user the copy of his competence.

Maintenance operations


The periodically maintenance operations consist in cleaning the main parts of the boiler, in the further functioning proof (especially those described by the laws in force), and in the eventual regulations, which could be necessary:

- ▶ verify the absence of the gas leakages from the connections upwards the boiler;
- ▶ verify the conformity, efficiency and good conditions of the connections to the boiler (water, gas, heating and electrical system);
- ▶ verify the presence of the permanent air/ventilation outlets, correctly dimensioned and working, as foreseen by the National and Local laws depending on the appliances installed;
- ▶ clean the burner, the exchanger and the funnel of the condense: go on as described in the paragraph "Combustion group cleaning and check" on page 31;
- ▶ check that the internal parts of the boiler are in good condition and clean;
- ▶ verify that the passage of the air burning and the evacuations of the flues and of the condense will be made correctly according to National and Local laws in force;

- ▶ verify the correct functioning of the system of the outlet condense, also in the external parts of the boilers, i.e. the eventual condense collector installed on the flue outlet: verify that the liquid flow is not obstructed and that there are not inlets of gaseous combustion products inside the system itself;
- ▶ verify that the conditions for the air intake are granted, in case of a boiler placed inside a piece of furniture;
- ▶ when prescribed, or if it is necessary (i.e. if you find excessive residual in the combustion group or in the funnel of the condense), verify that the combustion is correctly regulated: go on in this chapter as described in the paragraph "Combustion test" on page 36;
- ▶ verify the correct functioning of the boiler in heating and domestic hot water version;
- ▶ if necessary, vent the primary exchanger, proceeding as described in the paragraph "Venting the primary exchanger" on page 31;
- ▶ fill in the foreseen documentation and leave to the user the copy of his competence.

Access to the inside of the boiler

1. Unscrew the casing fixing screws **1** and **2**;
2. pull the casing **3** outwards, then push it upwards (to unhook it from the tongues **6**) and remove it;
3. unscrew the screws **5** and **6**, then slide the control panel **7** upwards and overturn it downwards. Then it's possible to remove the support **8** to better access the components;
4. after the regulations, close the boiler repeating everything in the other sense, carefully hooking the casing **3** to the tongues **4**.



Venting the primary exchanger

When commissioning the boiler, we recommend to check that there is no air in the primary circuit of the combustion unit. Do this operation also during the combustion unit cleaning, if you hear the typical air bubble noise.

- ▶ Locate the **combustion unit manual venting valve** (item **8** in the following picture) and, to avoid wetting the boiler inside, insert a length of flexible hose, with suitable diameter, on its fitting, then direct the other end towards a drain (or a container to collect the anti-freeze solution);
- ▶ start the "circuit venting" mode by activating the **Parameter 07** (see "Main boiler parameters (PC)" on page 33);
- ▶ slowly open the venting valve **8** and restore the system pressure when necessary;
- ▶ when no more air comes out from the venting valve **8**, close the valve and reset the **parameter 07** to **0**;
- ▶ restore the system pressure and, if needed, the concentration of additive liquid.

Combustion group cleaning and check



Switch off the boiler and disconnect it from the electrical supply.



Be sure that the parts are not hot and eventually wait the time necessary to cool them;



Because some contacts with the fine dust and acid condense may occur, we recommend to wear the proper devices for the personal protection (i.e. glasses, gloves, masque)




Warning: do not wash or damage the insulating coverings inside the combustion chamber.



The replacement of gasket on the ends of the pipe **04** is mandatory. Please get the original spares.

- ▶ Open the sealed chamber;
- ▶ disconnect the two connectors **2** from the fan;
- ▶ disconnect the connector **10** from the ignition/detection electrode **11**. **Attention:** do not dismount the electrode from the combustion group;
- ▶ remove the fastening clip **3**; unscrew the nut **5** which fixes the gas pipe **4** to the gas valve; pull out the gas pipe **4** from the fan/air-gas-mixer assembly;
- ▶ loosen the clamp **10** and pull the flexible air intake hose **11** out from the fan;



- ▶ unscrew, following the stamped sequence, the four nuts **1** which fix the burner group **12** (composed of fan, hose and burner) to the primary exchanger. Remove the burner group;

(i) Do not disassemble the burner group and do not dismount the ceramic fibre plate from the bottom of the exchanger.

- ▶ check the integrity of the insulating coverings inside the combustion chamber;
- ▶ on the burner cover, check the integrity of the fireproof fibre gasket and of the silicone rubber one;
- ▶ check that the burner do not present deposits, foulings or excessive oxidations and that all the holes are free;
- ▶ clean the cylinder of the burner **ONLY IF IT IS NECESSARY** and only **DRY**, through a **NOT METALLIC** brush, with movements on the burner's axis, from cover outwards;
- ▶ clean softly the burner electrode, and check that the minimum space is 3.4mm to 5.4mm;

(i) Do not damage the insulating coverings inside the combustion chamber and don't deform the holes of the burner. If the burner works correctly, it will be of black colour but clean or in any case with few deposits, not scaled and easy to remove.

- ▶ slip off the outlet condense pipe **9** from the connection on the siphon. It's advisable to put the end of the pipe in a container or to extend it with a suitable pipe, to divert the dust that detaches from the primary exchanger during the cleaning, outside the boiler;
- ▶ **to clean the primary exchanger:**
 - prior to brushing the exchanger's coils, carefully remove, by a powerful vacuum cleaner, the solid residuals of combustion; don't use air jets now;
 - then clean the primary exchanger coils by a **NOT METALLIC** brush and remove the residuals again by using the vacuum cleaner;
 - if necessary, clean the coils using compressed air;
 - vacuum clean the residues from the condense pipe **9**.

(i) If necessary, **use ONLY and EXCLUSIVELY water** to remove residuals.
The use of chemical products is forbidden.

- ▶ locate the lower cap **7** of the siphon and put a collector for liquids under it. Unscrew the cap. Let the siphon empty itself. Pour water into the combustion unit to rinse away any residues. Inside the cap **7**, a layer of residual could be present (max 1÷2mm): remove it;

Remark: *an excessive quantity of residual is an indicator of malfunctioning or in any case it is not a normal situation. Locate the reasons and solve the problem, so remove the siphon unscrewing the superior and lateral connectors, and the screw of its support bracket. Accurately clean the siphon and be sure that its condense inlet pipe **9** and condense outlet pipe **6** are clean and not obstructed.*


- ▶ Reassemble all the components in the backwards order and opposite sense and check the combustion.

PCB parameters settings (technician menu)

These settings are reserved to Technician only. The procedure how the get in the boiler parameters is known by technician only thanks to a combination of steps which allows to gain the boiler parameters.


A few of these settings allow to optimise and tailor the boiler working, while a few others allow to set the boiler during maintenance operation.

The 2-digits display on the left side of the display indicates the number of the parameter. Instead, the 3-digits display on the right side is referred to the parameter value (setting) the parameter is set on.






 In case of PCB replacing, check all of the parameter settings otherwise set them properly. Please, do not modify any firm setting if this is not required.

Main boiler parameters (PC)

The parameters listed in the following table are limited to those described in this handbook. The complete parameter list is available in the documentation for the technician.

Parameter	Adj. range (fact. set.) and values	Description
01	0...2 (0)	Type of GAS supply
	0	for Natural Gas (G20) supply
	1	for Commercial Propane (G31) supply
	2	Do not use this setting
	To change the type of gas supply, it is necessary to follow the complete instructions described in the paragraph "Gas conversion" on page 40.	
02	0; 1 (0)	Heating flow temperature setting range
	0	Normal setting, suitable for plants with radiators. This allows the user to adjust the system flow temperature, by acting on buttons + . . . III and - . . . III , within the high-temperature range
	1	Reduced setting, suitable for low temperature plants. This allows the user to adjust the system flow temperature, by acting on buttons + . . . III and - . . . III , within the low-temperature range.
<i>Remark: in case of mixed plants (with high and low temperature) thanks to optional kit, set low range (value 1) (please also refer to documentation provided with the kit).</i>		
03	—	It indicates the CH boiler power during the soft ignition phase. We recommend to leave the factory setting unchanged.
04	0...99 (*)	It indicates the CH boiler power according to the maximum nominal boiler power.
	<i>Remark (*): The factory setting depends on the model: see "Power adjustment tables" on page 38.</i>	
See details in "Max heating power adjustment" on page 38.		
05	0...2 (0)	Pump functioning mode during heating working
	0	intermittent for normal applications <i>(with eventual delay defined by parameter 06)</i>
	1	always on (to fit the needs of particular plants)
	2	always off (use only when external pumps are foreseen).
<i>Remark: The pump will be anyway activated in all other circumstances, e.g. during the DHW functioning or for anti-freezing or anti-lockout functions.</i>		
06	0...15 (3)	Value in minutes. Delay of boiler re-ignition after set Central Heating temperature has been reached.
	<i>(This parameter works only if par. 05 = 0)</i>	

Parameter	Adj. range (fact. set.) and values	Description
07	0...3 (0)	Auxiliary maintenance functions
	0	Disabled - normal operation of the boiler <i>(Remember to set this value to 0 at the end of work)</i>
	1	function Bleeding on heating side - boiler puts 3-way valve on the heating side and pump is continuously powered
	2	function Bleeding on DHW side - boiler puts 3-way valve on the DHW side and pump is continuously powered
	3	function Bleeding both Heating and DHW side - boiler cyclically moves the 3-way valve on heating and DHW sides, and pump is continuously powered
<i>Remark: Auxiliary maintenance functions stay active for about 15 minutes, then the parameter is automatically set back to 0. To stop the function manually, set the value to 0 or quit the Technical Menu.</i>		
08	0...2 (1)	Primary circuit working temperatures during DHW demand
	0	dynamics - Do not use in this type of boiler <i>(only for models with flow meter instead of flow switch)</i>
	1	fixed - burner OFF at 75°C and burner ON at 65°C
	2	linked to DHW SET: Burner OFF when DHW temperature + 3 ° C and burner ON when DHW temperature + 2 ° C
12	0...2 (0)	Chimney-sweeper" function: burner ignition, not modulated, to allow the combustion check. For deeper details see paragraph "Combustion test" on page 36.
	0	burner off - normal boiler work <i>(remember to reset this parameter to value 0)</i>
	1	burner ignition at maximum output
	2	burner ignition at minimum output
<i>Remark: During this phase, the delay between burner ignitions is zero, so if flow temperature is close to maximum, frequent re-ignitions of the burner could take place.</i>		
17	20...80	TA2 input setting (flow temperature during a CH request from the Secondary Room Thermostat only) <i>The boiler can manage a secondary room thermostat installed in a zone that must be heated with a different typology compared to the one where the primary room thermostat (or the original Remote Control) is installed. It's possible to foresee (with suitable hydraulic system solutions to distribute the heating to the various zones) a zone with a low temperature heating system (e.g. the primary one, controlled by the primary room thermostat or the original Remote Control) and one with radiators (controlled by the room thermostat TA2). The advantage of this management is that, when only the low temperature system requires heating, the boiler can work in low temperature and therefore condensing, with all the consequent advantages. Please note that the adjustment range is unique and it's extended to both the temperature typologies but, being a technical parameter, there's no possibility for the user to adjust (wrongly) the system flow temperature of the zone managed by TA2. Of course, the user will be able to adjust the room temperature of the secondary zone, by acting on TA2 itself.</i>



Parameter	Adj. range (fact. set.) and values	Description
22	0; 5...120 (0)	Enabling of Safety Thermostat on floor plant (on AUX input - see also parameter 46) and delay of its operating <i>Remark: avoid selecting values outside of the range described and correct if necessary.</i>
	0	Disabled - the component is not connected to AUX input
	5...120	Minutes of delay between the thermostat activation (open contact) and boiler block. <i>If the thermostat deactivates, the time count resets.</i>
23	0; 30...60 (0)	DHW temperature (storage preparation)
	0	By user controls - The adjustment of the DHW temperature is allowed to the User, by means of the buttons +  and - 
	30...60	User controls disabled - If there is some reason to disable the buttons +  and -  , and disallow the user to set the DHW temperature, choose a value different from 0 that will correspond to the set temperature.
25	0...10 (3)	Temperature hysteresis (°C) for storage preparation. It determines how many degrees has the DHW temperature to decrease compared to the set one, to generate a preparation request.
26	5...15 (8)	Differential (°C) for max flow temperature.
27	5...20 (15)	Differential (°C) among set DHW temperature and storage coil flow temperature, during preparation.
28	0; 50...70 (60)	Enables the anti-legionella function and sets the relevant temperature
	0	Disabled - the boiler won't run any anti-legionella cycle  Danger! This setting is strongly deprecated! Legionella is a bacteria that's extremely dangerous for the health and, in some cases, it can be deadly.
	50...70	Temperature at which the DHW storage is heated during the anti-legionella function.
29	1...15 (7)	Periodicity of the anti-legionella cycle (days).
30	1...30 (1)	Duration of the anti-legionella cycle (minutes). The duration starts from the reaching of the temperature set in Parameter 28.


Parameter	Adj. range (fact. set.) and values	Description
46	0...2 (0)	AUX input configuration - the AUX input (see "Electrical diagram" on page 51) can be set according to its use, to affect the boiler behaviour.
	0	Safety thermostat of Floor plant - When thermostat opens (open circuit), boiler blocks and shows a specific alarm. Both this parameter and no. 22 are factory set to 0 so, practically, AUX input is ignored.
	1	DHW Storage tank thermostat - when the contact is closed, the preparation (heating) of the DHW storage is forced.
	2	Room Thermostat 3 - with closed circuit, this contact activates heating demand at the same temperature of TA1 or Remote control.
49	0...20 (0)	Chooses the type of combustion calibration. <i>Remark: avoid selecting values outside of the range described and correct if necessary.</i>
	0	Manual (CO ₂ adjustment)
	5	Automatic (combustion system preset)

Combustion test

(i) if **burner and exchanger cleaning** is foreseen, carry it out before testing the combustion (see "Combustion group cleaning and check" on page 31).

To perform the test you need a **flue analyser, correctly calibrated** (in the condensing boiler, the precision and the correctness of the measures is particularly important). Then, through a suitable function on the panel, we ignite the burner, first with a reduced flow and then at the maximum flow, doing the measure and adjustments in both conditions. Proceed as follows:




1. the boiler should be electrically powered and set in **OFF**. Use the button  if necessary (only **OFF** has to be displayed on the screen);
2. on the flue flange, unscrew the screw **1** and move the tapping insert **2** in such a way to tap the intake plug **A** only; insert the analyser probe in the flue plug **F**, taking care of the seal of the connection;

Remark: The sensor placed at the top of the probe must be placed as possible in the centre of the flow outlet: we advise you to insert well the probe and so to extract it of 3 cm. Insert the probe so that the protection bow of the sensor, placed at the top, is transversal (the flow must pass through it and directly touch the sensor).




3. set the boiler in Heating  +  or Heating only  mode;
4. generate a heating request by activating the room thermostat.

 Be sure that the heat produced by the boiler can be eliminated by the heating system (through the radiators and/or radiant panels/floor systems).

5. activate the boiler to its **minimum output not modulated (Qr)**, by entering the technician menu and setting the parameter **12** to value **2** (see also "PCB parameters settings (technician menu)" on page 32);
6. Wait for the boiler to stabilize (about 5 minutes) then check, referring to the table, that the measured CO₂ value at **Qr** is within the allowed range;

Mod.	Heat input	Natural gas G20		Commercial propane G31	
		CO ₂ at Qn and ignition (%)	CO ₂ at Qr (%)	CO ₂ at Qn and ignition (%)	CO ₂ at Qr (%)
25	Nominal value	9.1	9.3	10.1	10.1
35	Allowed range	8.2 ... 9.7	8.4 ... 9.6	9.1 ... 11.1	9.0 ... 11.0

7. don't quit the technical menu and activate the boiler to its **maximum output not modulated (Qn)**, changing the value of the parameter **12** to **1**, wait for the boiler to stabilize and check, referring to the table, that the measured CO₂ value at **Qn** is within the allowed range;
8. if one or more CO₂ values was outside allowed ranges, carry out the MANUal combustion calibration (see "Combustion calibration" on page 38);
 - if the manual calibration doesn't allow to adjust the CO₂ to normal values, carry out an AUTO-matic calibration (remove the analyser during this operation) and then do a manual calibration again, measuring and adjusting the CO₂. If the problem persists, a fault in some component of the combustion system should be assumed.
9. quit the technical menu and set the boiler to  mode;



IMPORTANT: at the end of the check or the adjustments, it is INDISPENSABLE:

- close the flue plugs used, by restoring the tapping insert **2** and the screw **1**, caring that the plastic surface of the flange is not damaged or worn;
- check the correct flue system tightness, especially the tightness of the tapping insert **2**.

Power adjustment tables

	HEAT INPUT		Value of par. 4
	kW	kcal/h	
City Class 25 KR	MIN. 2.50	2150	00
	4.61	3965	10
	6.75	5805	20
	9.25	7955	30
	11,87	10208	40
	14,14	12160	50
	16,50	14190	60
	18,75	16125	70
	20.00	17200	78*
	20,75	17845	80
	23,20	19952	90
	MAX. 25.00	21500	99

	HEAT INPUT		Value of par. 4
	kW	kcal/h	
City Class 35 KR	MIN. 3.5	3010	00
	5.9	5117	10
	9.1	7800	20
	11.8	10148	30
	14.7	12625	40
	17.5	15016	50
	20.4	17578	60
	23.3	20029	70
	26.2	22558	80
	28.0	24080	83*
	29.1	24992	90
	MAX. 33.2	28552	99

* Factory setting

Max heating power adjustment

The maximum heating power output must be set in accordance with the system requirements (stated in the project) by using the parameter **04** (see page 33) with reference to the "Power adjustment tables" on page 38. The boiler is factory preset with a standard value, highlighted in the relevant table.

1. Get information about the maximum heating power requirement of the heating system (reported on the project documentation of the system itself);
2. ensure that there are NOT domestic hot water requests (no open taps) and that the heat produced by the boiler can be drained by the heating system;
3. enter the technician menu (see "PCB parameters settings (technician menu)" on page 32), select the parameter **04** and get ready to change its value. The burner ignites;
4. set the parameter **04** to the value that corresponds to the required power input (refer to the "Power adjustment tables" on page 38);
5. To switch the burner off, quit the technician menu (see also "PCB parameters settings (technician menu)" on page 32). The boiler switches to OFF mode.

The MAX power for the heating system is adjusted now.

Combustion calibration

Boiler is able to self-calibrate combustion in order to obtain correct CO₂ values on 3 different boiler power (minimum, average, maximum); moreover boiler keeps on checking combustion and makes little variations for always getting as better combustion as it can.

Boiler Calibration can be activated by a particular buttons sequences (know by the Technician) and it has 2 following options depending on the parameter 49 (see page 36):


- **AUTOMATIC:** this calibration is made during boiler production; on the field it should not be done **unless components linked to combustion have been replaced** (main PCB, Gas Valve, Fan, Primary exchanger, Burner, Electrode...). At the end of this procedure it is not allowed any change at val-


ues stored but boiler can work property with correct combustion values (even if they have to be checked with relevant instruments)

i During Combustion Calibration, flues tester should not be used because during this procedure, boiler can produce more than CO₂ needed and test result, in this condition, could not be accurate and truthfulness. **Combustion check with flues tester must be done after Calibration and not during it.**

- **MANUAL:** this calibration checks again the "Automatic calibration" done previously in production and allow the technician to modify a bit the results: +o- 3 steps where CO₂ % is changing about +o-0.6%; this means that every step changes +o-0.2% CO₂). Manual Calibration should be used when technician would like to make a more accurate calibration.

- ▶ Be sure that Parameter 49 is set to Combustion Calibration needed (AUTOMATIC or MANUAL)
- ▶ activate the Combustion Calibration with relevant buttons sequences (known by Technician);
- ▶ the display shows the writing **MANU** (or **AUTO** if the automatic calibration is deemed necessary);

Remark: in any moment, the calibration can be stopped by pressing the button , but the operation must be restarted and carried out completely in order to store the reference values in the system.


- ▶ once the ignition phase is finished, the system sweeps the three characteristic points: minimum, ignition and maximum, and displaying, respectively, **LO**, **ME** and **HI**.
- ▶ afterwards, in case of **MANU**al calibration, the CO₂ values can be adjusted:
 - select one of the phases **LO**, **ME** or **HI** by the buttons **+ .III** and **- .III** and wait for the stabilization of the CO₂ value on the analyser;
 - adjust the CO₂ value, if necessary, by the buttons **+ F** and **- F**;
 - proceed in the same way for the other two phases (eventually exclude the **ME**).
- ▶ Store the set by keeping the button  pressed for at least 2 seconds.
- ▶ If the value of the Parameter 49 has been modified to carry out the AUTO calibration, restore it to factory setting (see page 36).

Accessing the main board

The main PCB has no hardware adjustment devices onboard, so no access to it is required, except in case of cabling check or replacement of the board itself. Proceed as follows:

-  **Cut off the electrical supply to the boiler.** Restore the supply after having closed the control panel rear cover.

- ▶ unscrew the screws **1** and release the latches **2**;
- ▶ remove the back cover of the control panel.

-  **An incorrect or not complete closure of the electronic box voids the IP grade of protection of the appliance.** Ensure that all closing items are correctly used and that all cables pass through the suitable slots. If one or more latches **2** should break, please use holes **3** with suitable screws (similar to the standard ones **1**).



Main board replacement

Carefully follow the instructions included in the spare board kit.

Board configuration codes

Model	Gas G20 (1)	Conv. to G31 (2)
City Class 25 KR	30180	31180
City Class 35 KR	30380	31380

- (1) Factory preset; code written on the sticker on the electronic box
- (2) Code that will appear on the display (for some seconds at the moment of the electrical supply) if the Parameter 01 has been changed because of gas conversion.


Gas conversion



ATTENTION: the operations described below must be carried out only by qualified personnel.

This boiler is designed and prepared to be supplied with Natural Gas G20 (Methane). It can be set, just by means of electronic settings, but always by a qualified technician, to operate with Commercial Propane G31, for which it is absolutely necessary to install a pressure reducer upstream the boiler.

It must never be used with Butane gas G30 (that can be present, pure or mixed with Propane G31, in the portable gas bottles for cookers) therefore we recommend to inform, about this, the supplier of the fuel.

1. the boiler should be electrically powered and set in a mode different than **OFF**. Use the button  if necessary;
2. set the parameter **01** (see "PCB parameters settings (technician menu)" on page 32) on the required gas kind the boiler is required to work with:
 - **0 = Natural gas (G20),**
 - **1 = Propane (G31)**
3. ensure that the inlet gas pressure complies with the required nominal pressure (see "Technical data" on page 48) and that the gas flow is sufficient to guarantee the appliance correct work with burner ON;
4. we suggest to **clean the burner and exchanger** as described in the paragraph "Combustion group cleaning and check" on page 31 (**except** for the case of first ignition, new burner).
5. carry out the **AUTOMATIC combustion calibration** - see paragraph "Combustion calibration" on page 38 ;
6. carry out the **combustion test** - see paragraph "Combustion test" on page 36 ;
7. apply the label indicating the type of gas (provided with the kit) in the area provided on the "WARNING" plate inside the boiler; besides, write down the new configuration code of the main board (see table "Board configuration codes" on page 40)



In the case of liquid gas fuel, it is important that **the boiler be exclusively fuelled with commercial Propane G31** and not with Butane G30. For this reason, we recommend that **the supplier of the fuel be informed**, for example, **by applying a suitable warning on the gas tank** or in its immediate vicinity, **so that it is visible** to the employee at the time it is being filled.

Draining the heating system

When it is necessary to drain the heating system, proceed as described here below:



- ▶ Connect a rubber pipe to the draining tap terminal **1** ;
- ▶ put the other end of the pipe in a suitable drain or sink;
- ▶ open the draining tap by turning the nut **2** counter-clockwise, using a suitable spanner;
- ▶ when the pressure is COMPLETELY drained, it's possible to open the radiators venting valves, to allow the air inlet. The complete system drain is possible only draining the liquid from the lowest point of the system itself.

Remark: The complete system draining can be achieved only by draining the system from its lowest point.

- ▶ when everything is over, close taps (turning the nut **2** clockwise) and air vents.

(i) In the primary exchanger a certain quantity of water of the heating system remains. If you want to remove the boiler from the wall, we advice you to close with plugs the hydraulic inlet/outlet heating system connections.


- ▶ Drain the storage unit if necessary (storage tank and/or primary coil). Refer to the relevant documentation.



Pump settings

The pump has a selector which allows to reduce the speed, so as to reduce the noise produced by the too rapid circulation of the liquids in too small heating systems.

- **III = Maximum Speed** (Factory setting)
- **II = Medium Speed**
- **I = Minimum Speed** (use only if strictly necessary; test the heating system, verifying that no over-heating problems occur).












Alarms - boiler block









Following a malfunction, the boiler can lockout and show a particular signal, **RESET** or **SERVICE** on the display, with an alarm code "E...". In the following table, all the alarm signals are listed, their most probable causes and the suggested solutions. Generally:










- **RESET** identifies those **alarms the user can restore** by pressing the **RESET** button. It normally **blinks**, but after 5 reset actions in 24 hours the action on the **RESET** button has no more effect. *To have 5 further reset possibilities, it's possible to switch off the electrical supply to the boiler for 30 seconds, by using the purposed external switch, even if this work-around won't solve the problem and it will be necessary to call the Service Centre;*
- **SERVICE** identifies those **alarms the user can not restore**, as they are generated by the diagnostic system when a component has been detected as faulty. *The user is allowed to switch off the electrical supply to the boiler for 30 seconds, by using the purposed external switch, but should the alarm happen again, it will be necessary to call the Service Centre.*




















Operations accompanied by the symbol  are always reserved to the Technician. Operations with grey background are reserved to the Technician.

Signal	Probable causes	Suggested solutions
RESET E01	Boiler just installed (air mixed to gas).	<p>Retry the ignition several times: use the RESET button.</p> <p><i>When the 5 reset possibilities are over, to have 5 more, it's possible to switch off the electrical supply to the boiler for 30 seconds, by using the purposed external switch.</i></p>
	The flame has extinguished or it did not ignite	<p>Restore the boiler function by using the RESET button.</p> <p> In case of frequent blocks, verify the correct combustion, the good state and the cleaning of the burner.</p>
	 Incorrect combustion / flame detachment from the burner	<p>Check that the Intake/Outlet Ducts and the respective terminals are clean and in good condition, and that there are no leaks in them. During the installation, respect the regulation prescriptions, the slopes and the lengths (see "Flue systems" on page 22).</p> <p><i>Note for the TECHNICIAN: The burner flame is not detected by the control electronics because it has not turned on or it has suddenly turned off, or it has detached from the burner, because of an incorrect combustion. This can be due, in example, to combustion product reflow into intake duct, leaks in intake/outlet ducts or errors in sizing of ducts (ducts length out of the allowed range).</i></p>
	 Condensate drain problem	<p>Verify and restore the correct condensate drain.</p> <p> Warning! DO NOT open the combustion assembly before having cleared the drain and removed the condensate accumulated in the combustion chamber. <i>This alarm is caused by the condensate that, after having partially filled the combustion chamber, reaches the detection electrode and inhibits the detection of the flame ionisation.</i></p> <p>Then, check the combustion and verify that the burner is clean and in good conditions.</p>
RESET E02	the boiler has overheated and the Safety Thermostat has triggered	<p>Restore the boiler function by using the RESET button. If necessary, wait at least 20-30 minutes (to make the boiler cool) and try again. If the lockout persists or reappears, call the Service Centre.</p> <p> Verify the safety thermostat functionality. Detect the causes of the overheating, e.g. an insufficient circulation in the primary circuit; max gas pressure out of the limits or maximum heating power excessive for the heating system size.</p>
SERVICE E03	 The flue overheat thermal fuse has triggered (flue on boiler outlet too hot)	<p>Solve the problem that caused the overheating of the flue, then replace the flue thermal fuse.</p> <p><i>Note for the TECHNICIAN: the flue thermal fuse preserves the flue ducts (that are made with Polypropylene, a material suitable to the condensate acidity) from the high temperatures, that could lead to their fusion or deformation. The triggering of this device consists in its blowing and therefore it must be replaced.</i></p>
RESET E04	 Combustion check anomaly. Gas valve is supplied without flame presence.	<p>User: Try only one boiler reset by using the RESET button.</p> <p>If the lockout persists or reappears, call the Service Centre for required procedure</p>
SERVICE E05	 Failure to the system flow temperature probe.	<p>Check the cabling of the system flow temperature probe.</p> <p>Replacement of the system flow temperature probe.</p>

Signal	Probable causes	Suggested solutions
SERVICE E07 	Max number of alarms/blocks, of any kind, reached.	Boiler has blocked and has been reset many times. This proves that the boiler has a problem, so call the Service Centre. User: To attempt an interim restore, disconnect the electrical supply to the boiler by operating the suitable external bipolar switch, then connect it again after a few minutes.
SERVICE E08 	Max number of boiler alarms reached for no flame detection.	Combustion or burner has a recursive problem. Flame detection has been lost (with boiler block) for many times in a row. User: Try a boiler reset by using the RESET button. If the lockout persists or reappears, call the Service Centre.
SERVICE E09	Periodical Service maintenance	Call Service Technician for planned maintenance operations. <i>Pushing RESET, User can cancel this for 3 times. After that the signal remain on display. Even with this signal present, boiler is still working properly.</i>
RESET E10	Insufficient system pressure <i>(loss of water pressure switch triggered)</i>	Restore the correct pressure as described in "Preliminary operations" on page 9 or (preferably by the Technician) in "Heating system filling and pressuring" on page 19. <i>Remark: Consider that the pressure, in normal conditions, should not decrease with the progress of the time. If this happens, there is probably a loss in the heating system. Sometimes the loss is so small that it doesn't leave evident signs, but with the progress of the time it can cause the decreasing of the pressure. Also the opening of the manual venting taps of radiators (intentional or unintentional) makes the pressure decrease. Check that this doesn't happen.</i>
SERVICE E12 	Failure to the DHW storage temperature probe.	Check the cabling of the DHW storage temperature probe. Replacement of the DHW storage temperature probe. <i>Remark: If no probe is present (storage unit not installed or storage temperature managed by thermostatic contact or solar system) check that, on the storage temperature sensor terminals STB, a 2.2 kohm 1/2 W resistor is installed (this is factory preset, see "Electrical diagram" on page 51).</i>
SERVICE E13 	Gas modulator not connected.	Check the cabling of the gas valve's modulation command. Gas valve electrical circuit failure. Check/replace.
SERVICE E15 	Failure to the heating system return temperature probe.	Check the cabling of the system return temperature probe. Replacement of the system return temperature probe.
RESET E16 	Fan failure. The burner fan is stopped or rotates at an incorrect speed.	User: Try a boiler reset by using the RESET button. If the lockout persists or reappears, call the Service Centre. Check the burner fan functionality. Replace it if necessary.
E17 	Pushbutton failure. The electronic has detected the actuation of a pushbutton for more than 30 seconds.	User: check for jammed pushbuttons that remain pressed. Disconnect the electrical supply to the boiler by operating the suitable external bipolar switch, then connect it again after a few minutes. Remove the main PCB and clean, using suitable products, the rubber keyboard and pushbuttons' contact pads both on buttons and on the PCB. Replace damaged parts if necessary.
SERVICE E22 	PCB Software Error.	Call Service Centre for required procedure.

Signal	Probable causes	Suggested solutions
SERVICE E23 	Inlet electrical frequency not correct (50 Hz ± 1 Hz).	Call Service Centre for checking electric inlet signal.
RESET E24 	Floor heating system safety thermostat triggering: <ul style="list-style-type: none"> ▶ system flow temperature too high; ▶ floor heating system defective, faulty or malfunctioning. 	<p>The floor heating system and the floor cladding can be damaged by temperature shocks, so a good quality system includes one or more safety thermostats that, if necessary, trigger and lock the boiler.</p> <p>Try a boiler reset by using the RESET button (eventually wait for a period that allows to cool the system and restore the thermostat). If the lockout persists or reappears, call the Service Centre</p> <p><i>Remark: This alarm is in relationship with parameters 22 and 46 (paragraph "Main boiler parameters (PC)" on page 33. When this alarm is active, the hot water production is locked too.</i></p> <p> If any floor heating system was installed, check the correct setting of parameter 22 (see page 35).</p> <p>If the floor heating system is installed, check the system flow temperatures on the boiler and on the low temperature system kits (if installed). Replace the faulty or out-of-tolerance thermostats. Check the correct positioning of the thermostats on the system (see "Floor heating system" on page 15). Consider if the delay on the thermostat's triggering is too low and eventually, carefully, adjust it by increasing the value of parameter 22.</p>
SERVICE E25 	Automatic calibration needed.	Call Service Centre for required Combustion Calibration. See also "Combustion calibration" on page 38.
SERVICE E26 	Gas valve remains closed.	Call Service Centre for required procedure.
SERVICE E29 	Flues system completely or partially closed.	Call Service Centre for checking cleanliness of flues system, its capacity of aspiration/discharging and Gas inlet pressure.
SERVICE E31 	Remote control* not working <i>Data exchanged between the boiler and the Remote Control don't comply with the expected protocol.</i> <i>* This applies to Remote Control optional kit only, and not to third parties chrono-thermostats</i>	<p>User: Disconnect the electrical supply to the boiler for at least 30 seconds, by operating the suitable external bipolar switch, then connect it again and ensure that the Summer mode is selected by using the button . If the lockout persists or reappears, call the Service Centre.</p> <p>Problems on the optional Remote Control connection link (passing close to supply cables or other electromagnetic field sources; connection failure; cable length over 50 meters).</p>
RESET E35	Unexpected flame the control electronic has detected the flame on the burner when this one should be off	<p>Wait for the boiler automatic reset (5 minutes) or reset it manually by using the RESET button. If the lockout persists or reappears, call the Service Centre.</p> <p> Detect eventual malfunctioning of the gas valve (that does not stop fully the gas flow, so the burner remains ignited) or of the electronics, flame detection section (that detects the flame presence even if it's absent).</p>

Signal	Probable causes	Suggested solutions
SERVICE E38 	<p>Failure to the outdoor temperature probe (optional).</p> <p>The outdoor temperature probe, that was recognized and working, now results faulty.</p>	<p>User: Call the Service Centre.</p> <p><i>The boiler now works either in heating and in hot water, like as the external boiler had never been installed, so the heating system temperature is set directly and not as a function of the outdoor temperature. The alarm is displayed to inform that the accessory is no more efficient (consider that, on a first analysis, the boiler seems to work perfectly). Important: if the boiler is turned off and then on again, it's possible** that the alarm is no more displayed, even though the problem persists.</i></p> <p>Check the cabling of the outdoor temperature probe.</p> <p>Replacement of the outdoor temperature probe.</p> <p><i>** The alarm shows again only if the resistance of the probe is out of tolerance or in short-circuit. On the contrary, if the probe or the relevant cabling is interrupted, when the electrical supply is restored the boiler will consider the external probe absent and, in Winter mode, it will work in normal mode (temperature shifting disabled).</i></p>
SERVICE E39 	<p>Suspected freezing</p> <p>After a power failure, the boiler detected temperatures at the Heating and DHW probes equal to, or less than, 0°C when power was restored</p>	<p>The display shows the alarm code 39 while the boiler inhibits the ignition of the burner and activates the circulator, forcing water to circulate in the hydraulic circuits.</p> <p>If, during this time, the temperatures measured by the probes rise above +1°C, the alarm is reset and the boiler returns to the normal operation.</p> <p>Otherwise, the alarm will persist and you should suspect that water has frozen at one or more points of the hydraulic circuit of the boiler and/or system (with possible damage to the frozen parts). If the alarm persists, call a qualified technician.</p> <p> Find/replace the parts damaged by the freezing.</p>
RESET E43 	<p>Return overheat. About 90°C felt by CH return probe.</p>	<p>User: Try only one boiler reset by using the RESET button.</p> <p>If the lockout persists or reappears, call the Service Centre for required procedure</p>
SERVICE E44 	<p>Poor plant Circulation. Flow temperature increased too sharply.</p>	<p>Call Service Centre for required procedure.</p>
SERVICE E45 	<p>Return and flow probes inverted. Check CH probes (Flow and Return).</p>	<p>Call Service Centre for required procedure.</p>
SERVICE E47 	<p>Max number of no-flame detection events has been reached, mainly during the combustion internal check cycle. Refer to Alarm E08 for the probable causes and for the boiler reset actions suggested.</p>	
SERVICE E48 	<p>Max number of no-flame detection events has been reached, mainly after the ignition for a DHW request. Refer to Alarm E08 for the probable causes and for the boiler reset actions suggested.</p>	
SERVICE E49 	<p>Max number of no-flame detection events has been reached, mainly after the ignition for a CH request. Refer to Alarm E08 for the probable causes and for the boiler reset actions suggested.</p>	

Signal	Probable causes	Suggested solutions
SERVICE E50 	Minimum Inlet voltage not correct (Min 195V).	Call Service Centre for checking inlet signal.
SERVICE E74 	Anti-legionella function error (temperature reaching time-out).	Call Service Centre for required procedure.
SERVICE E78 	Combustion check anomaly. Gas valve current out of range.	Call Service Centre for required procedure.
SERVICE E79 	Combustion check anomaly. Check Fan not finished.	Call Service Centre for required procedure.
SERVICE E88 	Combustion check anomaly. Modulator Gas valve current too high.	Call Service Centre for required procedure.
SERVICE E90 	Combustion check anomaly. Flame detection signal too high for 1 instant.	Call Service Centre for required procedure.
SERVICE E93 	Combustion check anomaly. Flame detection signal too high for more than 10 sec.	Call Service Centre for required procedure.
SERVICE E99 	PCB generic anomaly	Call Service Centre for required procedure.

Warnings for servicing



All servicing operations and gas conversions **MUST BE CARRIED OUT BY QUALIFIED TECHNICIANS**, in compliance with the norms and laws in force (see an indicative list on page 4). Moreover, **MAINTENANCE** operations must be carried out in compliance with the manufacturer prescriptions and with the laws and rules presently in force, for the parts not mentioned in this handbook; we advice to perform them at least once a year to maintain the boiler's performance.

A careful servicing is always a guarantee of safety and energy saving. Normally, it will be necessary to execute the following operations:

- ▶ Remove any possible oxidization from burners and electrodes;
- ▶ Remove the scale from the exchangers;
- ▶ Cleaning and checking the exchanger, the siphon and all the parts which are in touch with the condense;
- ▶ Check integrity and stability of the insulating coverings in the combustion chamber and proceed eventually to substitution;
- ▶ Check and eventual substitution of the magnesium anode of the storage unit (see the documentation supplied with the unit);
- ▶ Check the boiler ignition, switching off and operation;
- ▶ Check the water and gas connections tightness;
- ▶ Check the gas consumption at the minimum and maximum output;
- ▶ Verify that safety devices are correctly working;
- ▶ Verify the correct functioning of control and adjusting devices;
- ▶ Verify periodically the absence of leaks of combustion products to the inner room, the correct functioning and the integrity of the flue outlet ducts and/or devices and of the relevant terminals and accessories;
- ▶ In case of works or servicing of the structures placed near the above mentioned ducts and /or devices and their accessories, switch off the boiler;
- ▶ Do not leave any inflammable tanks and/or substances in the installation room;
- ▶ If the boiler draws directly from the installation room (*type B appliance installed indoor*): Do not clean the room where boiler is installed, while it is working
- ▶ Clean casing with soapy water only. Do not clean casing, other painted or plastic surfaces with thinner.
- ▶ In any case of parts replacement, it is mandatory to use ITALTHERM original spare parts.

ITALTHERM declines any responsibility in case of non-original spare parts utilization.


Technical data

TECHNICAL DATA		U.M.	City Class 25 KR		City Class 35 KR	
Gas type			G20	G31	G20	G31
Class			II _{2H3P}		II _{2H3P}	
Type			B23 - B23P - B53 - B53P - C13 - C33 - C43 - C53 - C63 (C13-C33-C53-C83) - C83 - C93			
Working temperature range (min÷max)	°C		0 ÷ +60		0 ÷ +60	
Max heat input Q _n	kW	25.0	25.0	33.2	33.2	
Max heat input in heating mode	kW	20.0	20.0	28.0	28.0	
Min heat input Q _r	kW	2.5	2.5	3.5	3.5	
Max heat output 60°/80°C *	kW	19.4	19.4	27.4	27.4	
Min heat output 60°/80°C *	kW	2.4	2.4	3.3	3.3	
Max heat output 30°/50°C *	kW	21.0	21.0	29.5	29.5	
Min heat output 30°/50°C *	kW	2.7	2.7	3.7	3.7	
NO _x Class		6	6	6	6	
CO at 0% O ₂ (Q _n)	ppm	230.1	217.0	169.0	205.5	
CO ₂ at nominal input	%	9.00	10.04	9.00	10.20	
Condense quantity at Q _n (30°/50°C *)	l/h	2.5	2.5	3.0	3.0	
Condense quantity at Q _r (30°/50°C *)	l/h	0.3	0.3	0.4	0.4	
Condense acidity	pH	2.8	2.8	2.8	2.8	
Flue temperature, Max.	°C	61.5 <small>60/80° Q_r</small>	61.5 <small>60/80° Q_r</small>	64.0 <small>60/80° Q_n</small>	64.0 <small>60/80° Q_n</small>	
Flue temperature, Min.	°C	41.0 <small>30/50° Q_r</small>	41.0 <small>30/50° Q_r</small>	38.0 <small>30/50° Q_r</small>	38.0 <small>30/50° Q_r</small>	
Flue mass flow rate (60/80°C *, Q _n)	kg/h	41.11	41.86	54.60	54.41	
Flue mass flow rate (60/80°C *, Q _r)	kg/h	3.94	4.22	5.76	5.63	
EFFICIENCY						
Nominal efficiency at 60°/80°C *	%		96.1		96.2	
Nominal efficiency at 30°/50°C *	%		105.1		106.4	
Efficiency at 30% load at 30°/50°C *	%		106.4		106.7	
* system return / flow water temperature; NCV = Net Calorific Value (=Hi) Remark: data have been measured with horizontal coaxial flue, length = 1 m.						
HEATING						
Temperature selection range (min÷max) <i>Main heating circuit, normal range / low temp. range</i>	°C		35÷80 / 20÷45			
Temperature selection range (min÷max) <i>Secondary heating circuit</i>	°C		20÷80			
Characteristics of the heating system water (or filling liquid) (* = if aluminium parts are present along the system)	°f pH		5 ÷ 15 °f pH 7.5 ÷ 9.5 (7.5 ÷ 8.5 *)			
Expansion vessel	l		8		10	
Expansion vessel pre-loading pressure	bar		1		1	

(follows)


TECHNICAL DATA <i>(cont'd)</i>	U.M.	City Class 25 KR		City Class 35 KR	
		G20	G31	G20	G31
Loss of water pressure switch off / on pressure	bar	0.4 / 0.9 (±0.2)		0.4 / 0.9 (±0.2)	
Max working pressure	bar	3		3	
Max system temperature	°C	90		90	
Anti-freezing function temperature on / off	°C	5 / 30		5 / 30	
HOT WATER					
Temperature selection range (min÷max)	°C	30÷60		30÷60	
ELECTRICAL DATA					
Voltage / frequency (nominal voltage)	V / Hz	220÷240 / 50 (230V)		220÷240 / 50 (230V)	
Power consumption	W	135		150	
Level of protection		IP X5D		IP X5D	
DIMENSIONS					
Width - Height - Depth	mm	see "Dimensions and connections" on page 14			
Weight: net / gross	kg	28.4 / 30.8		33.8 / 36.2	
CONNECTIONS					
Hydraulic and gas connections		see "Dimensions and connections" on page 14			
Flue: types, lengths and diameters		see "Flue systems" on page 22			
Fan head loss	Pa	20 ÷ 130		15 ÷ 130	
GAS SUPPLY PRESSURE					
Nominal pressure	mbar	20	37	20	37
Inlet pressure (min÷max)	mbar	17 ÷ 25	35÷40	17 ÷ 25	35÷40
GAS CONSUMPTION					
Q _{max}	m³/h	2.64		3.51	
	kg/h		1.94		2.57
Q _{min}	m³/h	0.26		0.37	
	kg/h		0.19		0.27

Boiler internal components



- | | | | |
|----|--|----|--|
| 1 | Flue connection flange | 15 | Gas valve |
| 2 | Plug for Combustion analysis (air intake) | 16 | System pressure gauge |
| 3 | Plug for Combustion analysis (flue) | 17 | By-pass (in-built in the 3-way valve hydraulic assembly) |
| 4 | Expansion Vessel | 18 | Motorized 3-way valve |
| 5 | Water drain pipe from air intake flange | 19 | Siphon for condense outlet |
| 6 | Fan | 20 | Manual Venting Device (Combustion assembly) |
| 7 | Air/Gas Mixing device | 21 | Temperature Sensor, system flow |
| 8 | Temperature Sensor on system return | 22 | Safety thermostat on system flow |
| 9 | Loss of water pressure switch | 23 | Air intake hose |
| 10 | Automatic Venting Device (heating circuit, incorporated in the pump) | 24 | Flame ignition/detection electrode |
| 11 | Safety valve 3 bar | 25 | Combustion assembly (burner+primary exchanger) |
| 12 | Pump | 26 | Flue overheat fuse |
| 13 | Pipe for condense outlet | | |
| 14 | Drain valve | | |

Electrical diagram



- 6.1 Fan - supply
- 6.2 Fan - speed control
- 8 Temperature Sensor on system return
- 9 Loss of water pressure switch (*)
- 12 Pump
- 15 Gas valve
- 18 Motorized 3-way valve
- 21 Temperature Sensor, system flow
- 22 Safety thermostat on system flow (*)
- 24 Ignition and flame detection Electrode
- 26 Flue overheat fuse
- 61 Fuse F2A (2A fast)
- 62 Resistor, 2.2 kOhm - 1/2W (**)

(*) the contacts of these components are shown in rest conditions (cold condition, no system pressure, no flow)

(**) see "Electrical connection between the boiler and the storage unit" on page 21 for details.

Optional external devices:

STB DHW Storage temperature sensor (**)

TB DHW Storage thermostat (*) (**)

TA Room thermostat: (or Chronothermostat) SELV simple contact. Closed contact = heating request.
or **Remote control** (original accessory only)

SE To optional outdoor temperature sensor

TA2 To optional room thermostat for zones with different temperature range


AUX Input for optional device (also for DHW Storage thermostat **TB**) configurable with Parameter 46 (see page 36).

Abbreviations: COM Common • NC Normally closed (contact) • NO Normally open (contact)
• HEA Heating (diverting command) • DHW Hot water (diverting command)

Colours: BK Black • BN Brown • BU Blue
• GN Green • RD Red • OG Orange • VT Violet
• WH White • YE Yellow • YG Yellow-Green
(↔ possible colours alternatives)

Hydraulic diagram

This diagram is for information only. To make boiler hydraulic connection either see "Dimensions and connections" on page 14 and eventually "Positioning and fastening" on page 16.



- | | |
|---|--|
| 1 Flue connection flange | 21 Temperature Sensor, system flow |
| 4 Expansion Vessel | 22 Safety thermostat on system flow |
| 5 Water drain pipe from air intake flange | 23 Air intake hose |
| 6 Fan | 71 Flue hood |
| 7 Air/Gas Mixing device | 72 Combustion chamber |
| 8 Temperature Sensor on system return | 73 Burner |
| 9 Loss of water pressure switch | 74 Primary exchanger |
| 10 Automatic Venting Device (heating circuit, incorporated in the pump) | 75 Gas pipe |
| 11 Safety valve 3 bar | 76 Inlet of water from air intake in the condense siphon |
| 12 Pump (including automatic venting device) | 77 Tap for condense siphon cleaning |
| 14 Drain valve | 78 Condense drain in combustion assembly |
| 15 Gas valve | |
| 16 System pressure gauge | R Heating return |
| 17 By-pass (in-built in the 3-way valve hydraulic assembly) | M Heating flow |
| 18 Motorized 3-way valve | RB Return from storage coil |
| 19 Siphon for condense outlet | MB Flow to storage coil |
| 20 Manual Venting Device (Combustion assembly) | SC Condense drain |
| | G Gas inlet |



Outdoor Sensor Kit


Installation and setting

The Outdoor Sensor manages automatically the CH flow temperature** as a function of the outdoor temperature, thus avoiding the user to adjust it manually. This function is also named "shifting temperature".

** that's the temperature of the heating elements. Don't mistake it with the room temperature (managed by the room thermostat or by the Remote Control, but not by the boiler) that doesn't depend on the first one.

The installation must be made by a professionally skilled technician following the instructions supplied with the kit. Refer to "Electrical diagram" on page 51 for the links to the Main Board.

After the installation of the Sensor, the buttons **+|||** and **-|||** described in the User section (see page 10) won't adjust directly the CH flow temperature, but the dispersion factor "**kd**" that's the response of the outdoor temperature, detected by the sensor, on the CH flow temperature, as shown in the following graph.



Practically, **kd** value should be adjusted depending on the estimated efficiency of the building's thermal insulation. Its range is from 01 to 30: use **higher values** when there is a **high thermal dispersion** and therefore a **less efficient insulation** (and vice versa).

(i) Because of the wide buildings typologies, it's impossible to give precise indications on kd value to set. **The correct setting must be determined case by case and will have, as a result, an optimal comfort in all the climatic conditions** requiring heating, i.e. a prompt reaching of the room temperature with cold weather and no room overheating during mild periods.

Outdoor Sensor kit and Remote Control

If also the Remote Control Kit is installed, please refer to the relevant instruction handbook for details about the combined working of Outdoor Sensor and Remote Control itself.

Remote Control Kit

This remote control is **more than a simple room thermostat**. Thanks to this, it is possible to **manage the boiler in all its settings** like DHW and CH temperature adjustment, **boiler reset** in case of boiler block, and of course it works as a **room thermostat** both in **manual** and **weekly program** mode. It's powered by the boiler (in safety low voltage), so **it doesn't need batteries**.



(i) Extract the Remote Control from its package. **Keep the relevant user instruction booklet and annex it to this Manual.**



Nor the Remote Control neither the relevant cable coming from the boiler must not, for any reason, be connected to the 230Vac supply mains.



To avoid malfunctions due to electrical noise, the Remote Control connections, as well as all low-voltage connections, should be kept separated from power supply cables, e.g. by enclosing it into separate raceways.

The maximum overall cable length shouldn't exceed 50 m.

1. Cut off electricity from boiler;
2. install the device as described in the **paragraph 1** of the supplied instruction booklet;
3. connect the terminals "**OT**" nr. **1-2** of the Remote Control to the "TA - Room Thermostat - Remote Control" cable coming out of the boiler, by means of a suitable bipolar terminal. See also "Electrical diagram" on page 51;

Note: *The Remote Control link is not polarized.*

4. power supply the boiler and select the **Summer** mode;
5. check the correct work of the device. The electronics should recognize it automatically.



Hereafter, the boiler should be left on Summer mode; the boiler work is managed by the Remote Control, including the OFF, Summer and Winter modes, and the technical functions (such as several additional functions).

In case of problems in wirings or in boiler setting, the alarm E31 will appear. See E31 alarm description on page 44.



www.italtherm.it



ITALTHERM S.p.A. declines any responsibility for eventual printing and/or transcription errors in the present manual. In order to constantly improve its products, the company has the right to change features and data written in the present manual, at any time and without notice.

960000140_00
20220901